Milwankee SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS REVISED BULLETIN DATE May 2025 PACKOUT™ Rolling Storage WIRING INSTRUCTION SERIAL CATALOG NO.



**EXAMPLE:**  $00|_{\frac{0}{0}}$ Component Parts (Small #) Are Included When Ordering The Assembly (Large #).

1 2

## 48-22-8426 PACKOUT™ Rolling Tool Box

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
2		Screw	(2)
3	48-22-8027	Retractable Handle Service Assembly	(1)
4		Screw	(2)
5	43-62-8426	Side Handle Svc. Kit (Contains 2 Side Handles and 4 Pi	ins) (1)
6		Pin	(4)
7	48-22-8098	Wheel Svc. Kit (Contains 2 Wheels and 2 Locking Hex N	Vuts) (1)
8		Locking Hex Nut	(2)
9	44-20-8400	Latch Service Assembly (Set of 2)	(1)
10	31-01-8400	Storage Tray	(1)
11	43-44-8400	Lid Gäsket (Not Shown)	<b>}</b> 1}
12	42-12-8426	Axle Svc. Kit (Contains 1 Axle and 2 Locking Hex Nuts)	(1)
		,	` '



As an aid to removing a damaged Latch Assembly (9), use two large flat blade screwdrivers. Push blades between parts as shown. Twist both screwdrivers at same time to force the blades into opening and work the latch assembly over the two locking tabs.

To install a new latch assembly, position entire latch assembly over locking tabs with the two top lugs partially inserted in 'catch cavity' of main housing. Engage latch bar onto lid and gently press latch lever to slide assembly over two locking tabs and into place.

This removal and installation process will be the same where other service latches are offered in this system.

