



SERVICE PARTS LIST

SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS		REVISED BULLETIN	DATE
1-1/8" ROTARY HAMMER		54-24-5025	Aug. 2007
CATALOG NO. 5360-21	SERIAL NUMBER 410B (410A Series II)	WIRING INSTRUCTION 58-01-1866	

EXAMPLE:
 Component Parts (Small #)
 Are Included When Ordering
 The Assembly (Large #).




FIG.	PART NO.	DESCRIPTION OF PART	QTY.	FIG.	PART NO.	DESCRIPTION OF PART	QTY.
3	12-20-5360	SERVICE NAMEPLATE KIT	1	252	45-22-0467	SLEEVE	1
8	45-88-1245	WASHER	1	253	45-22-0469	SLEEVE	1
9	44-90-0340	SNAP RING (EXT.)	1	254	02-02-0100	BALL	6
10	31-15-0257	CRANKCASE COVER	1	255	40-50-8900	SPRING	1
102	31-15-0255	BRUSH COVER	2	256	44-90-0350	RETAINING RING (EXT.)	1
119	05-78-0745	TAPTITE SCREW	5	257	48-66-3044	SDS-PLUS ADAPTER	1
127	05-78-0715	SCREW	7	259	45-88-1270	WASHER	2
200	31-40-0042	GEARCASE	1	260	45-88-1187	WASHER	1
204	44-86-0625	SPLINED RETAINER	1	261	44-10-0077	SHIFT LEVER	1
206	31-15-0307	CRANKCASE	1	262	44-66-0101	PLATE	1
208	45-88-8825	WASHER (ADD AS REQUIRED)	1	265	44-96-0101	ROLLER	4
209	34-40-4440	O-RING	1	266	02-02-0110	BALL	4
210	02-80-6025	THRUST BEARING SET	1	267	05-77-0030	BOLT	1
211	14-73-0247	WOBBLE SHAFT ASSEMBLY	1	268	45-88-1182	WASHER	1
212	36-66-3162	REDUCTION GEAR SHAFT	1	269	45-88-1183	WASHER	1
214	45-88-1250	WASHER	1	270	44-90-0115	RING	1
215	40-50-8897	SPRING	1	271	45-88-1184	WASHER	1
216	45-22-0302	COUPLING SLEEVE	1	272	45-88-1185	WASHER	1
★ 217	45-88-8414	WASHER	1	273	45-88-1186	WASHER	1
218	36-92-0747	WOBBLE PLATE	1	275	05-74-0700	SCREW	2
219	32-60-2622	REDUCTION GEAR	1	276	05-74-0717	SCREW	2
220	32-60-2157	OFFSET GEAR	1	415	45-60-0511	BEARING ASSY	1
221	32-60-2165	INTERNAL GEAR	1	420	36-66-4267	INTERMEDIATE GEAR SET	1
222	44-82-0192	RAM	1	426	45-88-1170	RETAINING RING	1
223	44-62-0157	PISTON	1	427	45-88-1280	WASHER	1
224	44-60-1405	WRIST PIN	1	430	45-56-2539	STRIKER ASSEMBLY	1
225	45-88-1180	WASHER	2	600	43-46-0172	DEPTH GAGE (NOT SHOWN)	1
226	44-90-4500	SHIFT RING	1	★ 701	49-15-5300	SIDE HANDLE (NOT SHOWN)	1
228	44-60-1485	PIN	1	1100	31-44-0011	HANDLE SET	1
★ 229	44-66-6055	RETAINING PLATE	1	1204	34-40-4454	O-RING	1
232	38-50-0059	FIXTEC SPINDLE	1	1207	43-44-0375	GASKET	1
233	40-50-7977	BELLEVILLE SPRING	5	1209	34-40-5359	O-RING	1
★ 234	45-88-7767	STOP WASHER	1	1210	34-40-4452	O-RING	1
★ 235	32-10-0055	SPINDLE GEAR	1	1211	34-40-4451	O-RING	1
236	40-50-8492	RETAINING RING (EXT.)	1	1212	34-40-4459	O-RING	1
237	45-88-1255	WASHER	1	1213	34-40-4453	O-RING	1
238	02-80-0150	THRUST WASHER	1	1214	42-76-0267	QUIK CHANGE COLLAR	1
239	45-88-0775	RETAINING RING	1	1215	43-87-0080	ISOLATION BLOCK	1
243	42-76-0727	THRUST COLLAR	1	1218	44-90-4415	RETAINING RING	1
248	45-88-1265	WASHER	1	1219	44-90-0350	SNAP RING (EXT.)	1
251	02-50-2185	NEEDLE BEARING	2	1220	05-74-0685	SOCKET HEAD SCREW	4
				1222	05-74-0695	SOCKET HEAD SCREW	2
				1223	05-74-0697	SCREW	2
				1224	34-40-0132	O-RING	1
				★ 1225	45-06-0215	FELT WASHER	1
				1226	38-50-0013	FIXTEC SPINDLE KIT	1

Type "P" Grease (Cat. No. 49-08-4250)


1. Place 1/2 oz. at needle bearing / splined retainer area of gear case (200).
2. Grease assembled wobble shaft assembly (211) with 1/2 oz. of grease.
3. Place 1/8 oz. in armature pinion / intermediate shaft assembly (420) cavity.
4. Place 1/4 oz. of grease in wobble shaft drive gear cavity of crankcase (206).
5. Grease clutch (235) and clutch springs (233) on spindle (232) with 1/8 oz. of grease.

NOTE: Total amount used; 1 1/2 oz. (one complete tube)

Type "Q" Grease (Cat. No. 49-08-4255)

1. Coat the spindle (232) inside and out.
2. Coat all parts assembled on or in spindle except for clutch.
3. Coat piston (223) (inside and out), ram (222), wrist pin (224) and wrist pin washers (225). DO NOT coat the flat face of the ram.

NOTE: Total amount used; 3/4 oz. (1/2 of a full tube)





Torque (in lb.)	Description	Thread Locking Sealant
22	Motor/armature bolts (2)	None
22	Motor housing bolts (4)	None
9	Cord Clamp screws (2)	None
85	Anti-vibration post (1)	None
10	Handle screws (3)	None
16	Motor cover screws (4)	None
50	Spindle retaining bolts (2)	Blue
22-26	Gearcase screws (4)	None

SERVICE NOTES:

5360-21

1. To remove the gearcase (200), remove the retaining ring (1219, 256), shift lever (261), plate (262), screws (1223), adapter (257), collar (1214), sleeves (252, 253), spring (255) and washer (260).
2. To remove the spindle (232), the two mounting bolts (275) must be removed with a 4 mm allen wrench.
3. To remove ram (222) from the catacher, tap the end of striker assembly (430) with a screwdriver. Ram may be found in piston rather than in ram catcher.
4. To remove striker assembly (430) from spindle (232), remove internal retaining ring (1218) with a small screwdriver by pushing on the ring through the two small ports in the spindle where the ring is visible. Push the ring in and towards the open end of the spindle.
5. To remove spindle gear/clutch (235), press the spindle gear against the disk springs (233) and remove retaining ring (236).
6. To remove wobble shaft assembly (211), turn the wobble shaft so the wobble finger of plate (218) leans toward the gearcase (200). Pull out on the shaft, tilt and pull it to get it to clear the crankcase (206).
7. To disassemble wobble shaft assembly (211), press reduction gear (219) off, remove all remaining parts.
8. To remove bearing housing (415), try turning/twisting on the lugs by hand. If it will not move, use a large, flat-blade screwdriver.
9. To remove the handle (1100), push out dowel pin (7), open handle, remove snap ring (9) and washer (8) from the isolation block (1215), disconnect field leads and remove handle.
10. To remove motor, remove two screws (1222) from the top of the crankcase (206) and 4 screws (1221) Disconnect field leads and slide motor out of crankcase.
11. To remove armature (406) from motor assembly, pull brushes (1201) off of commutator, push back brush holders (120) to provide clearance for insulating disc (410), slide bearing cover (130) from under ball bearing (409) and slide armature out.
12. When reassembling bearing housing (415) to crankcase (206) do not press it completely into place before the piston (223) and wobble shaft (211) are in place.
13. When reassembling the wobble shaft assembly (211), a clearance of .001 to .003 inch must be maintained between the reduction gear (219) and the inner race of the wobble plate (218). The ground side of the gear must face the wobble plate.
14. When reassembling the clutch be sure to stack the disk springs (233), as shown. (Refer to Note 18)
15. To install internal retaining ring (1218) into spindle (232), use an old, used piston.
16. Check slugs (117 and 1216), replace if worn or missing.
17. Bearing cup (1205) to be placed in motor cover (401) before assembly.



Service Notes – How to check the Static Slip of Clutch Mechanism

Note! Before checking the ‘static’ slip clutch torque a tool’s clutch assembly must be dynamically slipped for a minimum of 5 seconds; to dynamically slip the clutch assembly requires drilling with the tool and ‘binding a bit in the work’ and slipping the clutch faces for 5+ SECONDS.

Parts required to check the ‘Static Torque’ of Slip Clutch of the 5303-20 & 5360-21 Rotary Hammer are as follows.


- Chuck Adapter # 48-03-3047
- ½” - 20 Hex Nut



Checking ‘static’ torque — 5360-21

- remove SDS chuck adapter # 48-66-3044 from the hammer
- insert the 48-03-3047 chuck adapter with a ½”-20 hex nut threaded onto the adapter
- turn / place shifting lever into the “hammer with rotation mode”
- remove the four (4) screws from the motor cover
- remove the motor cover from the crankcase
- place hammer upside down in a machinist vise and tighten securely
- install ¾” socket onto ft-lbs torque wrench, which corresponds to hex of ½”-20 nut
- hold the armature firm by holding onto the fan
- turn torque wrench in a clockwise direction (as viewed from the bit end of the tool) while holding the armature fan, observe at what value the clutch slips

Service Notes – Disassembling the spindle – Assembling gear reduction shaft



Disassembling the spindle

- 1) remove spiral retaining ring [A]
- 2) remove
 - washer, o-ring, two (2) thin washers, thrust bearing & thick washer assembly [9]
 - retaining plate [8]
 - shift ring [7]
- 3) remove spindle gear [4] with the aide of a 90° external snap ring pliers and 61 30 0290 press fixture (see illustration & Product Support Bulletin #271 & #324) - compress the spindle gear against the belleville spring washers [1] while removing retaining ring [6]
- 4) remove flat washer [5]
- 5) remove four roller pins [3] and stop washer [2]
- 6) remove the four (4) steel balls [B] — compress the five (5) belleville spring washers [1] using ‘pipe’ press fixture to compress the assembly which will allow for removal of steel balls with the help of a magnetized tip screwdriver - press fixture can be made from 1 3/8” pipe (see illustration below) — failure to use press fixture can cause damage to top belleville spring washer or all belleville spring washers – requiring replacement before re-assembling



Press Fixture for removal of steel balls made from 1 3/8” Black or Galvanized Pipe cutting four [4] notches 90° from each other.

NOTE: Tools having spindle kit 38-50-0013 will not have flat washer #5.






fig 6 is X1 control washer see step 4 to determine if needed




Assembling the reduction gear shaft

1) assemble the reduction gear shaft [8] with the following parts:

- washer [9]
- spring [10]
- coupling sleeve [11]
- wobble plate [1]

2) press reduction gear [2] onto reduction gear shaft [8] with the ground face toward wobble plate; a clearance of 0.001" to 0.003" **must be maintained** between the reduction gear [2] and inner race of the wobble plate [1]



3) lightly **grease entire length of reduction gear shaft** [8] and coupling sleeve [11] - lightly grease the thrust bearing assembly [3,4,&5] and place them onto the shaft


4) check for control dimension X1 of 3.954" to 3.980", if < 3.953" **add a single 45-88-8825 0.020" washer** [6] to the assembly

5) place o-ring [7] on shaft, it serves to hold thrust bearing assembly (and if needed the 0.020" washer) in place

6) assemble internal gear [12], offset gear [13] and 45 88-1182 washer [14] and 45-88-1183 washer [15] onto wobble shaft assembly

7) recess of 45-88-1183 washer [15] must face needle bearing / front of gear case

8) check for control dimension **X2**, if it does not fall between 3.678" – 3.690" chose a suitable washer(s) according to chart and add it (them) to the reduction gear shaft assembly - if required place control washer(s) [16] in front of 45 88-1182 washer [14], sandwiching it (them) between 45 88-1182 washer [14] and 45-88-1183 washer [15]



control dimension X2 — 3.678" – 3.690"
measured between face of 45-88-1183 washer [15] & face of flat washer [5], see illustration below
add washer(s) [16] to the assembly as needed to obtain X2 control dimension
most, if not all hammers will require control washer(s)

		control washer(s) [16] added to the assembly as listed		
		0.039" 45-88-1186	0.016" 45-88-1185	0.008" 45-88-1184
control dimension X2				
3.621	3.622	1	-	1
3.622	3.630	1	1	-
3.630	3.638	1	-	1
3.638	3.646	1	-	-
3.646	3.654	-	2	-
3.654	3.661	-	1	1
3.662	3.669	-	1	-
3.670	3.677	-	-	1
3.678	3.690	-	-	-

