



Parts List for DW911 Type 2

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
2	429790-42	LATCH ASSY.	1
3	429790-43	PCB ASSEMBLY	1
4	429790-44	FRONT HSG	1
5	429790-45	HOLDER ASSY.	1
6	5140019-43	CHARGER ASSY.	1
7	429790-19	DOOR ROD	1
8	429790-18	HOLDER BASKET	1
9	429790-56	ANTENNA	1
10	429790-57	ANTENNA	1
11	429790-47	ANTENNA CONTACT	1
12	429790-23	HOUSING GASKET	1
13	429790-17	HANDLE	1
14	429790-38	ROLL CAGE-LEFT	1
15	429790-20	SHOCK MOUNT	4
16	429790-48	TRANSFORMER	1
17	429790-09	TUNING KNOB	1
18	429790-12	MODE KNOB	1
19	429790-10	VOL. KNOB	1
20	429790-49	FOOT	1
21	429790-25	PAD	8
22	429790-50	LATCH PLATE	1
23	429790-13	CORD WRAP (L)	1
24	429790-14	CORD WRAP (R)	1
25	429790-51	LOGO PLATE	4
26	429790-40	POWER PCB ASSY	1
27	429790-29	AUX JACK COVER	1

Parts List for DW911 Type 2

Item Number	Part Number	Description	Qty Required
28	429790-52	AUX.INPUT P.C.B	1
29	429790-37	ROLL CAGE-RIGHT	1
30	429790-54	SPEAKER ASSY	1
31	5140019-09	FUSE	1
32	429790-32	FUSE,1A	1
33	429790-33	POWER CORD	1
34	429790-34	CORD BUSHING	1
35	098091-10	SCREW	1
36	330045-05	LOCK SCREW	1
37	429790-57	ANTENNA	1
846	429790-53	HARDWARE BAG	1