

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
1	42-09-1020	Antenna	(1)
2	23-45-2050	Speaker Kit	(1)
3	31-15-2175	Door Kit	(1)
4	22-09-0580	PC Board Kit	(1)
5	42-44-0225	Aux Input Cable	(1)
6	12-20-2125	Service Nameplate Kit	(1)
7	23-81-0700	Wall Transformer (Not Shown)	(1)
8	31-15-0880	Battery Cover	(1)

NOTES

FIG.

6

A clean, dry surface is essential for proper performance for any adhesive system. The area intended for application of any adhesive label or nameplate must be prepared by cleaning with isopropyl alcohol. The solvent is to be applied with a clean, lint free applicator and the surface allowed to dry before applying the label or name plate. PC Board Kit 22-09-0580

Aux Input Connector

Antenna Connector

NOTE:

As part of the assembly process, tops of wire trap posts are slightly melted over to secure wires. When replacing Speaker Kit or PC Board Kit, side cutters or a small grinder can be used to open the trapping posts to free the old wires. Install new service kits and route wires as shown. Secure the wires with a dab of RTV adhesive at the trap locations.

Speaker Kit 23-45-2050

FRONT RADIO HOUSING

PC Board Kit 22-09-0580



