



BOSCH

Angle Grinder

----- | 0 601 323 160

Table of Content

Spare parts list.....	2
Illustration - Type.....	5

Spare parts list

Item	Part Number	Description	Illustration
2	1 604 336 008	Brush Holder	1
3	1 604 220 099	Field 115V	1
6	1 604 652 015	Spiral Spring	1
8	1 605 500 089	Sealing cap BLUE	1
9	1 605 132 083	Handle BLUE	1
11	1 602 381 006	Insulating Plate 20x20x50 MM	1
12	1 600 703 009	Grommet Ø11,5-Ø15,0x150 MM	1
13	1 604 460 203	Power supply cord GB 110V 4,15m 2 x 1,5mm H07RN-F	1
14	1 607 328 034	Suppression Filter	1
15	1 601 302 013	Fastening Clamp	1
17	1 601 037 006	Cover Plate	1
20	1 605 808 054	Bearing cover	1
21	1 600 102 012	Cover Disc	1
22	1 603 523 032	Grinding Spindle M14x1,5 MM	1
23	1 600 108 055	Sealing disk	1
24	1 607 000 229	Assembly Of Service Parts	1
25	1 600 306 001	Grommet	1
26/1	1 605 806 324	Gear Housing SILVER	1
27	1 600 910 010	Needle bearing Ø22x11,3 MM	1
28	1 600 206 014	Rubber Ring 10 MM WIDE	1
29	1 600 502 007	Air-Deflector Ring	1
30	1 600 116 002	Retaining ring	1
31	1 601 11A 3H3	Nameplate	1
32	1 600 290 008	Rotary shaft lip seal WHITE	1
34	1 600 190 004	Shim 0,1 MM THICK	1
34	1 600 190 005	Shim 0,2 MM THICK	1
35	1 601 030 022	Tab Washer	1
36	1 600 502 006	Rubber Bushing	1
38	1 601 110 062	Manufacturer's nameplate	1
39	1 601 110 358	Reference Plate CAUTION	1
43	1 601 110 058	Reference Plate DOUBLE INSULATION	1
44	1 603 344 051	Threaded Ring	1
45	1 600 116 004	Retaining ring	1
48	1 608 039 008	Storage Ledge	1

Spare parts list

Item	Part Number	Description	Illustration
50	1 900 905 227	groove ball bearing 6203-2 Z DIN 625	1
51	2 916 620 011	Retaining ring Ø22 MM	1
52	1 600 900 020	groove ball bearing 17x35x10	1
52	1 900 905 234	groove ball bearing 15x35x11	1
53	1 600 900 029	groove ball bearing	1
54	2 910 021 118	Socket head cap screw DIN 84-AM4x8-8.8	1
55	2 910 021 050	Socket head cap screw DIN 84-AM3x8-8.8	1
55	2 910 211 006	Tapping Screw DIN 7971-BZ2,9x13	1
56	2 916 060 003	Spring Washer A 3 DIN 137-ST	1
57	2 910 021 157	Socket head cap screw DIN 84-AM5x15-8.8	1
58	2 915 011 005	Hex Nut DIN 934 -M4-m-8	1
59	1 613 435 009	Tapping Screw ST-4,8x57,5-TORX,T20	1
60	2 910 021 158	Socket head cap screw DIN 84-AM5x16-8.8	1
60/1	2 910 211 036	Tapping Screw DIN 7971-ST4,8x25-F	1
61	2 910 021 162	Socket head cap screw DIN 84-AM5x20-8.8	1
63	1 603 410 001	Socket head cap screw DIN 84-BM5x82	1
63	1 603 435 006	Tapping Screw B4,8x90 MM	1
64	2 916 680 006	Spring Lock Washer DIN 127-B 5	1
65	1 600 150 006	Spring Washer DIN 137-A4	1
66	2 910 021 122	Socket head cap screw DIN 84-AM4x12-8.8	1
68	2 910 021 196	Socket head cap screw DIN 84-AM6x15-8.8	1
69	2 910 211 011	Tapping Screw DIN 7971-BZ3,5x13	1
71	1 600 101 650	Shim 0,05 MM THICK	1
72	1 600 101 648	Shim 0,1 MM THICK	1
73	1 600 101 649	Shim 0,15 MM THICK	1
650	1 602 025 09Z	Auxiliary Handle	1
650	1 602 025 0A1	Auxiliary Handle	1
652	1 605 510 082	Protective Cover Ø230 MM (9")	1
652/2	2 910 141 242	Hex Socket Head Cap Screw DIN 912-M8x20-8.8	1
800	1 607 014 103	Carbon-Brush Set	1
801	1 605 108 902	Assembly Of Service Parts BLUE	1
804	1 606 333 158	Bevel Gear Z=61	1
808	1 604 011 242	Armature 115V	1
809	1 607 200 064	Switch	1

Spare parts list

Item	Part Number	Description		Illustration
809/00/04	2 910 091 118	Pan head screw	DIN 85-AM4x8-4.8	1

Illustration - Type - E

