



BOSCH

Jig Saw

----- | 0 601 588 039

Table of Content

Spare parts list.....	2
Illustration - Type.....	5

Spare parts list

Item	Part Number	Description	
1	2 605 104 580	Housing Section	BLUE
2	1 604 220 195	Pole Shoe	100V
3	2 604 011 152	Armature	120V
3/90	2 606 610 093	Fan	
4	2 607 200 345	Switch	
5	2 604 460 226	Power supply cord	
6	2 600 703 018	Grommet	Ø7,3-Ø8,6x76 MM
7	2 601 302 011	Fastening Clamp	
9	2 601 119 942	Manufacturer's nameplate	
14	2 600 905 095	Ball Bearing	9x24x7
16	2 605 807 083	Brush Plate	
19	2 603 490 021	Torx Oval-Head Screw	4x12
28	1 903 201 042	Needle Roller	DIN 5402-A3x11,8-G2
29	2 916 660 008	Spring retaining ring	DIN 472-24x1,2 MM
31	2 600 101 048	Shim	0,5 MM
32	2 600 913 040	Needle-Roller Assembly	
33	2 606 320 101	Eccentric Cog Wheel	
34	2 600 102 614	Shim	0,5 MM
35	2 601 923 010	Fork Lever	
36	2 601 098 032	Counterweight	
37	2 600 101 047	Shim	0,3 MM
38	2 916 080 909	Locking Washer	DIN 6799-6-FST
40	2 600 200 038	Intermediate Ring	
41	2 600 917 900	Needle bearing	
42	2 602 305 048	Air Eliminator	
51	2 603 105 053	Bearing bolt	
52	2 600 590 006	Ratchet Cap	
53	2 602 026 063	Rotary Knob	BLACK
54	2 916 080 908	Locking Washer	5 DIN 6799
55	2 602 026 065	Rotary Knob	BLACK
56	2 600 100 607	Shim	0,3 MM
57	2 603 100 069	Straight Pin	17,35+0,1 MM
60	2 605 808 081	Gear Cover	
60/20	2 600 301 037	Bushing	
61	2 604 610 042	Compression Spring	

Spare parts list

Item	Part Number	Description
63	2 600 101 095	Shim
65	2 601 015 064	Seal
74	2 604 651 011	Torsion Spring
75	2 600 591 010	Cap-Handle BLACK
76	2 601 015 065	Seal
77	2 601 016 079	Cover Plate
78	2 603 421 014	Thread-forming tap. Screw
83	2 600 202 037	Retaining snap ring
85	2 601 015 057	Sealing Plate
89	2 601 098 082	Work Board
90	2 601 030 022	Profile Beading
91	2 910 141 197	Hex Socket Head Cap Screw DIN 912-M6x16-8.8
92	2 917 760 034	Slotted Spring Pin 2x6 DIN 1481
94	2 603 410 049	Thread-forming tap. Screw M4x12 MM
95	2 603 101 046	Protecting Cover BLACK
97	2 604 448 211	Earth Conductor
98	2 603 490 018	Torx Oval-Head Screw 3x18
99	2 601 010 062	Dust Protection
100	2 602 026 066	Switch Handle BLACK
101	2 601 099 072	Adjusting Slide
102	2 604 611 033	Compression Spring
104	2 604 448 104	Connecting Cable L=63 MM WHITE
107	2 603 490 024	Torx Oval-Head Screw 4x25
108	3 604 440 527	Connecting Cable L=63 MM WHITE
653/10	2 605 510 159	Covering hood
655	2 601 016 065	Splintering Protector
808	2 601 119 927	Reference Plate
810	2 602 026 902	Switch Handle
816/04	2 604 320 913	Carbon-Brush Set
816/06	1 604 652 013	Spiral Spring
825	2 605 806 896	Gear Housing
844	2 600 326 904	Roller Set
845	2 601 321 904	Roller Lever
860	2 605 808 927	Gear Cover

Spare parts list

Item	Part Number	Description	
862	2 601 322 900	Guide Bracket	
866	2 600 780 911	Lifting Rod	
873	2 601 990 906	Holding Plate	
881	2 600 290 902	Seal Kit	
886	2 605 500 908	Fan Cover	BLUE
888	2 608 000 917	Base Plate	
888	2 608 000 920	Base Plate	

Illustration - Type - E

0 601 588 003
 Stand }
 Issue } 08-04-14

Fig./Abb. 1

