


10.1.1 PTJ-Series Pallet Trucks – Exploded View



10.1.2 PTJ-Series Pallet Trucks – Parts List

Index No	Part No	Description	Size	Qty
1	PT2748A-001A	Handle		1
2	PT2748A-002A	Handle Cap		1
3	PT2748A-003A	Lever		1
4	PT2748A-004	Spring Pin	5x16mm	1
5	PT2748A-005	Bolt	M8x20	1
7	PT2748A-007	Spring Pin	3x28mm	1
8	PT2748A-008	Oil Lite Bushing		1
9	PT2748A-009	Roller		1
10	PT2748A-010	Roller Pin		1
11	PT2748A-011	Release Rod		1
13	PT2748A-013	Chain		1
14	PT2748A-014	Anchor Bolt		1
15	PT2748A-015	V-Nut	M8	1
16	PT2748J-101B	Dust Seal *		1
17	PT2748J-101B	O-Ring *	29.8x3.5mm	1
18	PT2748J-101B	U-Packing *	30x38x6mm	1
19	PT2748J-101B	O-Ring *	4.8x1.9mm	2
20	PT2748J-101B	Dust Seal *		1
21	PT2748J-101B	U-Packing *	18x26x5	1
23	PT2748J-101B	O-Ring *	6x1.9mm	1
24	SB-14MM	Steel Ball	14mm	1
25	PT2748J-025	Ram Piston		1
26	PT2748A-026	Oil Plug		1
28	PT2748J-101B	O-Ring *	11.6x2.4mm	1
29	PT2748A-029	Release Screw		1
30	PT2748A-030	Spring	10x2.3x27mm	1
30A	PT2748A-30A	Valve		1
31	SB-6MM	Steel Ball	6mm	1
32	PT2748A-032	E-Ring	15mm	1
33	PT2748L-033	Plunger Piston		1
34	PT2748A-034	Spring Cap		1
35	PT2748A-035A	Spring	38x5x121mm	1
36	PT2748A-036	Release Plug		2
37	PT2748A-037	Washer	20mm	1
38	PT2748A-038	Spring	8x1.5x12.8mm	1
38A	PT2748A-038A	Spring	4.8x0.7x15mm	1
39	PT2748A-039	Valve Housing		1
40	SB-6MM	Steel Ball	6mm	2
40A	SB-9MM	Steel Ball	9mm	1
41	PT2748A-041	Spring Pin	3x28mm	2
42	PT2748A-042	Spring Pin	8x25mm	1
43	PT2748A-043	Snap Ring	44mm	1
44	PT2748A-044	Spring Pin	8x45mm	1
46	PT2748A-046A	Wheel Shaft (<i>all models except PT-1636J</i>)		1
	PT1636J-046A	Wheel Shaft (<i>PT-1636J only</i>)		1
47	PT2748J-109A	Pump Housing Assembly (<i>all models</i>)		1
48	PT2748A-048	Handle Pin		2
49	PT2748A-049	Bearing Base		1
50	BB-51109	Ball Bearing	51109	1
51	PT2748A-051	Spring	6.3x1.2x25mm	1
52	PT2748A-052	Release Nozzle		1
53	PT2748A-053A	Cam		1

* Available only in the repair kit – PT2748J-101B

Index No	Part No	Description	Size	Qty
54	PT1636J-054	Spring Pin.....	6x30mm	2
55	PT2748A-055A	Table (<i>all models except PT-1636J</i>).....		1
	PT1636J-055A	Table (<i>PT-1636J only</i>).....		1
55B	PT2748A-055B	Grease Fitting.....		1
56	PT2748A-056	Snap Ring.....	25mm	2
57	PT2748A-057	Snap Ring.....	20mm	2
60	PT2748L-103A	Steer Wheel Assembly W/Bearings.....		2
60A	BB-6205VV	Steer Wheel Ball Bearing.....	6205VV	2
60B	BB-6304VV	Steer Wheel Ball Bearing.....	6304VV	2
61	PTX2748-056	Dust Seal Cap.....		2
62	TS-1550111	Washer.....	20mm	2
67		Fork Frame (N/A).....		1
69	TS-1551061	Lock Washer.....	8mm	2
70	TS-1504031	Socket Head Cap Screw.....	M8x14	2
71	PT2748A-071	Crank Shaft (<i>PT-2742J / PT-2748J</i>).....		1
	PT2048A-071	Crank Shaft (<i>PT-2036J / PT-2042J / PT-2048J</i>).....		1
	PT1636J-071	Crank Shaft (<i>PT-1636J Only</i>).....		1
74	PT2748A-074	Table Pin.....		2
75	PT2748A-075	Oil Lite Bushing.....		2
76	PT2748J-076A	Lifting Yoke (<i>PT-2742J / PT-2748J</i>).....		1
	PT2048J-076A	Lifting Yoke (<i>PT-2036J / PT-2042J / PT-2048J</i>).....		1
	PT1636J-076A	Lifting Yoke (<i>PT-1636J Only</i>).....		1
77	PT2748J-077	Spring Pin.....	6x35mm	1
78	PT2748J-078A	Arm Pin.....	16x145mm	2
79	PT2748J-079	Spring Pin.....	5x25mm	2
80	PT2748J-080BN	Black Nylon Load Wheel W/Bearings.....		2
80A	BB-6004VV	Load Wheel Bearing.....	6004	4
81	PT2748J-079	Spring Pin.....	5x25mm	2
81A	PT2748J-081A	Snap-Ring.....	20mm	4
82	PT2748J-082	Load Wheel Axle.....		2
83	PT2748J-083A	Arm.....		2
86	PT2748J-086A	Rod Pin.....	16x96mm	2
88	PT2736J-088A	Rod (<i>PT-1636J / PT-2036J</i>).....		2
	PT2742J-088A	Rod (<i>PT-2042J / PT-2742J</i>).....		2
	PT2748J-088A	Rod (<i>PT-2048J / PT-2748J</i>).....		2
89	PT2748A-089A	E-Ring.....	19mm	2
99	PT2748A-099A	Release Rod Assembly (index #11,13-15).....		1
	PT2748J-101B	Repair Kit (index # 16-23, 28).....		1
	PT2748J-109A	Pump Assembly (<i>all models except PT-1636J</i>).....		1
	PT1636J-109A	Pump Assembly (<i>PT-1636J only</i>).....		1
	PT2748J-110A	Pump, Handle, Wheel Assembly (<i>all models except PT-1636J</i>).....		1
	PT1636J-110A	Pump, Handle, Wheel Assembly (<i>PT-1636J Only</i>).....		1
	PT1636J-ID-A	I.D. Label (not shown).....		1
	PT2036J-ID-A	I.D. Label (not shown).....		1
	PT2042J-ID-A	I.D. Label (not shown).....		1
	PT2048J-ID-A	I.D. Label (not shown).....		1
	PT2742J-ID-A	I.D. Label (not shown).....		1
	PT2748J-ID-A	I.D. Label (not shown).....		1
	PT2748J-JET	JET Logo Label (not shown).....		2
	PT2748J-WL	Warning Label (not shown).....		1
	PT2748J-PL	Pump Label (not shown).....		1