



REPLACEMENT PARTS

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	1237902	UPPER PULLEY COVER <i>INCL.</i> :	62	1237813	SWITCH COVER
<i>NOT SHOWN</i>	1243501	M4x10mm SLOT CHEESE HD SCR	63	1310547	M4.2x12mm PAN HD TAP SCR
<i>NOT SHOWN</i>	1243569	M4mm HEX NUT	64	1237812	SWITCH
<i>NOT SHOWN</i>	1320102	M4.1mm LOCK WASHER	65	1310155	M5x8mm PAN HD SCR
1A	901193	SPEED CHART	66	1320101	M5.3mm EXT TOOTH WASHER
1B	1237903	NAMEPLATE	67	901168	RING
2	1310065	KNOB	68	1243339	M6x8mm HEX SOC SET SCR
3	1237904	STRAIN RELIEF(6N3-4)	69	1237914	TABLE BRACKET ASSY, <i>INCL.</i> :
4	1310547	M4.2x12mm PAN HD TAP SCR	70	1237915	HANDLE LOCK
5	1246002	M6x12mm CHEESE HD SCR	71	1237916	M16mm WAVE WASHER
6	1310061	M6.4mm FLAT WASHER	72	1237917	M16mm FLAT WASHER
7	1310056	GROMMET	73	1237918	STUD
8	1237905	LOWER PULLEY COVER <i>W/HINGE</i>	74	1235840	M12mm FLAT WASHER
9	1342455	M5x10mm PAN HD SCR	75	1237937	M12mm WAVE WASHER
10	1340719	CORD CLAMP	76	1343492	M12mm LOCK NUT
11	1237911	SLEEVE	77	1237919	ECCENTRIC PIN
12	1312019	RETAINING RING	78	1237920	PIVOT BOLT
13	1312053	BALL BEARING	79	1237921	HOOK HANDLE
14	1312018	SPACER	80	1237922	M8mm LOCK NUT
15	1237912	V-BELT(A26)	81	1237922	M8mm LOCK NUT
16	1343342	V-BELT(A27)	82	1237929	SPRING
17	1312028	BALL BEARING	83	1237923	M4x20mm PAN HD SCR
18	1346232	CENTER PULLEY	84	1237924	SPRING RETAINER
19	1312029	SHAFT	85	1311009	WORM GEAR
20	1311071	KEY	86	1311007	PINION GEAR
21	1312024	MOTOR PULLEY	87	1310016	5mm DRIVE SCR
22	1330200	M8x12mm HEX SOC SET SCR	88	1237925	ANGLE SCALE
23	1311061	SPECIAL PULLEY NUT	89	1311008	SHAFT
24	1346233	SPINDLE PULLEY	90	1237926	THREAD CLAMP BLOCK
25	1312023	MOTOR	91	1237927	CLAMP BLOCK
26	1246034	M8x20mm HEX HD SCR	92	1237928	QUICK COLUMN HANDLE LOCK
27	1243476	M12mm HEX NUT	93	1237930	HANDLE ASSY
28	904-02-020-1705	1/2" LOCK WASHER	93A	1243321	M6x10mm HEX SOC SET SCR
29	1311029	MOTOR BRACKET	94	1312008	RACK
30	1312012	RIGHT MOTOR TENSION ROD	95	1310595	COLUMN ASSY, <i>INCL.</i> :
31	1312031	LEFT MOTOR TENSION ROD	96	1311003	M10x12mm HEX SOC SET SCR
32	1243526	M8.4mm FLAT WASHER	97	1246029	M10x40mm HEX HD SCR
33	1243398	M8mm HEX NUT	98	1312001	BASE
34	1311067	MOTOR CORD	99	1344329	M8x125mm HEX HD SCR
35	1311072	POWER CORD	100	1243526	M8.4mm FLAT WASHER
36	1237906	HEAD	101	1246157	M8.1mm LOCK WASHER
36A	1246110	M6x24mm SPRING PIN	102	1243398	M8mm HEX NUT
37	1310016	5mm DRIVE SCR	103	428-06-101-0002	3mm HEX WRENCH
38	1232994	WARNING LABEL	104	432-07-101-0004	5mm HEX WRENCH
39	901171	THUMB LOCK SCR	105	1237931	STOP ROD
40	1343304	RUBBER WASHER	106	1237932	DEPTH SCALE
41	1310105	M8x16mm HEX HD SCR	107	1346045	STOP NUT ASSY, <i>INCL.</i> :
42	1311026	ECCENTRIC	108	1346046	SPRING
43	1237907	TENSION HANDLE	109	1346047	RELEASE
43A	1237908	EXT RET RING	110	1246155	M6x12mm FLAT HD SCR
44	1311003	M10x12mm HEX SOC SET SCR	111	1237933	MOUNTING BRACKET
45	1346024	GRIP	112	1312053	BALL BEARING
46	1343327	HANDLE BAR	113	1343492	M12mm LOCK NUT
47	1340708	PINION ASSY. <i>INCL.</i> :	114	1346049	CLAMP NUT
48	1330410	M5x20mm SPRING PIN	115	1346205	M6x46mm HEX HD SCR
49	1346026	HUB	116	1243303	M6x12mm HEX SOC SET SCR
50	1237909	M5x10mm FLAT HD SCR	117	1237934	STOP COLLAR
51	1237910	CHUCK KEY SOCKET	118	1312014	RUBBER WASHER
52	901192	HANDLE LOCK	119	1311065	SHIFTER
53	1311048	SPECIAL SCR	120	1237935	QUILL
54	1243360	LOCK WASHER	121	920-04-020-5335	BALL BEARING
55	1243496	M10mm HEX NUT	122	1311054	M17.5mm FLAT WASHER
56	1311046	SPRING RETAINER	123	1311055	RING
57	1310082	SPRING ASSY	124	1311056	LOCK NUT
58	902-01-010-1227	1/2-20 HEX NUT	125	1237936	SPINDLE
59	1312025	SWITCH BOX	126	1312021	ARBOR
60	1246098	M5x16mm CHEESE HD SCR	127	1312022	5/8" CHUCK <i>INCL.</i> :
61	1237938	SWITCH PLATE	128	1313105	CHUCK KEY

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta International Machinery Corp. strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repair. Any product which is presented to a Delta Authorized Service Center for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair. This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your local service outlet.