



### Parts List for 1921 Type 3

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
2	000000-00	No Longer Available	1
3	000000-00	No Longer Available	2
4	000000-00	No Longer Available	1
5	000000-00	No Longer Available	1
6	000000-00	No Longer Available	2
7	000000-00	No Longer Available	4
8	000000-00	No Longer Available	1
9	450054-00	BATTERY PACK	1
10	65630-00	SCREW	1
11	92555-00	CHUCK & KEY	1
12	330019-13	SCREW,M4X19	2
13	000000-00	No Longer Available	1
14	000000-00	No Longer Available	1
15	091817-00	WASHER	2
16	091644-00	THRUST BEARING	1
17	000000-00	No Longer Available	1
18	000000-00	No Longer Available	1
19	030612-00	PLUG	1
20	000000-00	No Longer Available	1
22	000000-00	No Longer Available	1
24	000000-00	No Longer Available	3
25	330003-04	BEARING,BALL	1
26	000000-00	No Longer Available	1
28	000000-00	No Longer Available	1
29	330034-00	KEY,CHUCK	1
30	000000-00	No Longer Available	1

### Parts List for 1921 Type 3

Item Number	Part Number	Description	Qty Required
31	000000-00	No Longer Available	1
32	000000-00	No Longer Available	2
33	000000-00	No Longer Available	1
34	000000-00	No Longer Available	1
35	91874-00	SPRING	1
36	000000-00	No Longer Available	1
37	000000-00	No Longer Available	1
38	000000-00	No Longer Available	1
800	761995-01	GREASE, 6 OZ.	1
801	283484-01	GREASE,32 OZ.	1
871	449240-01	CHARGER	1