


ENGINE PARTS - MODEL 2075RC

2-CYCLE GAS TRIMMER

(Serial Number 802115993 and greater)




Item	Part No.	Description	Item	Part No.	Description
1	181704	Cylinder	39	181741	Washer
2	181705	Cylinder Base Gasket	40	181742	Rope
3	181706	Bolt	41	181743	Pull Handle
4	181707	Insulator	42	181744	Pulley Assembly
5	181708	Insulator Gasket	43	181745	Ratchet
6	181709	Carburetor Gasket	44	181746	Spring
7	181710	Screw	45	181747	Retaining Ring
8	181711	Muffler Assembly (includes 9 & 10)	46	181716	Screw
9	181712	Muffler	47	181748	Throttle Bracket
10	181713	Screw	48	181749	Carburetor (includes Primer Bulb)
11	181714	Muffler Gasket	49	181750	Screw
12	181715	Muffler Plate	50	181751	O-Ring
13	181716	Screw	51	181752	Air Cleaner Assembly (includes 52 thru 55)
14	181717	Crankcase Service Assembly (includes 15 thru 19 & 25)	52	181753	Sleeve
15	181718	Crankcase Gasket	53	181754	Choke Plate
16	181719	Bearing	54	181755	Choke Lever
17	181720	Oil Seal	55	181756	Screw
18	181721	Oil Seal	56	181757	Air Filter
19	181722	Snap Ring	57	181758	Air Cleaner Cover
20	181723	Screw	58	181967	Clutch Housing Assembly
21	181724	Piston	59	181760	Engine Bolt
22	181725	Ring	60	181761	Nut
23	181726	Piston Pin	61	181762	Screw
24	181727	Snap Ring	62	181968	Engine Cover
25	181728	Crankshaft	63	181716	Screw
26	181729	Key	64	181764	Screw
27	181730	Clutch	65	181765	Spark Plug
28	181074	Clutch Washer	66	181629	Screw
29	181731	Spacer	67	181774	Fuel Tank (includes 70)
30	181732	Flywheel Assembly	68	180000	Fuel Cap Assembly
31	181733	Module Assembly	69	181767	Fuel Line Assembly
32	181734	Spacer	70	181768	Screw
33	181735	Screw	71	181769	Lead Wire Assembly
34	181777	Recoil Assembly (includes 35 thru 41)	*	612468	Compression Spring
35	181737	Recoil Case	*	181696	Spark Arrestor
36	181738	Recoil Pulley	*	181701	Primer Bulb
37	181739	Recoil Spring	*	181702	Carburetor Repair Kit
38	181740	Screw	*	181703	Gasket/Diaphragm Repair Kit

* not shown

BOOM AND TRIMMER PARTS - MODEL 2075RC

2-CYCLE GAS TRIMMER

(Serial Number 802115993 and greater)



Item	Part No.	Description
1	180866	Grip
2	181688	Throttle Cable Assembly
3	180975	Throttle Trigger
4	610314	Throttle Trigger Spring
5	181689	Throttle Trigger Assembly
6	180252	Switch Assembly
7	181690	Wire Lead Assembly
8	181971	Drive Shaft Housing Assembly
9	610327	Shoulder Strap Clamp
10	180869	Loop Handle Assembly (Includes 11)
11	180870	Handle Mounting Hardware
12	181773	Drive Shaft
13	180547	Guard Mount Screw Assembly
14	180548	Guard and blade Assembly
15	180553	Blade Assembly
16	153597	Lower Clamp Assembly (Includes 17)
17	145569	Anit-rotation Screw
18	180549	Gearbox Assembly
19	153599	Outer Spool and Eyelet
20	610660	Retainer
21	610317	Spring
22	610318	Inner Reel
23	153066	Bump Head Knob Assembly

Optional Accessories

- * 610375 Replacement Line
- * 153577 Reel and Line Assembly
- * 682075 Shoulder Strap Assembly
- * 147543 Ryobi 2-Cycle Oil

* not shown