
SERVICE PARTS LIST

Milwankee. SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS **REVISED BULLETIN** DATE Mar. '99 MAG STAND CONTROL PANEL WIRING INSTRUCTION **SERIAL** CATALOG NO. 23-35-0321 SEE BELOW NUMBER **EXAMPLE:** Component Parts (Small #) Are Included **DESCRIPTION OF PART** FIG. PART NO. When Ordering The Assembly (Large #). Circuit Board Assembly (1)2 23-33-0495 Receptacle Assembly (1) Panel Plate Assembly (1)3 44-66-0810 4-40 x 3/8" Pan Hd. Taptite T-9 06-82-5268 (4)



- 1. ROUTE TWO MAGNETIC BASE LEADS (RED WIRES WITH YELLOW SLEEVING) THROUGH ADJUSTING PLATE AND PAST ADJUSTING LOCK MECHANISM, ONE ON EACH SIDE. MAKE SURE SLEEVING IS NOT ABRADED DURING ROUTING.
- SECURE LINE CORD IN SUPPORT HOUSING.
- ATTACH GROUND TERMINAL TO SUPPORT HOUSING WITH GROUND SCREW. POSITION GROUND WIRE TERMINAL AS SHOWN, SO IT CAN SET FLAT AGAINST HOUSING BEFORE SECURING.
- ATTACH THE BLACK AND WHITE LEADS FROM LINE CORD, AS SHOWN.

- ATTACH THE LEADS FROM THE MAGNETIC BASE. AS SHOWN. NOTE: THE LEADS FROM THE MAGNETIC BASE CAN BE ATTACHED TO THE PANEL IN EITHER LOCATION.
- 6. ATTACH THE POTTED PCB ASSEMBLY TO THE SUPPORT HOUSING.
- 7. GENTLY PUSH THE BUNDLE OF WIRES DOWNWARD AND INSTALL THE CONTROL PANEL INTO THE HOUSING. AVOID PINCHING WIRES OR THE RIBBON CABLE AS THE CONTROL PANEL IS BEING INSTALLED.

MILWAUKEE ELECTRIC TOOL CORPORATION 13135 W. LISBON RD., BROOKFIELD, WI 53005