



Parts List for 23-725 Type 3

Item Number	Part Number	Description	Qty Required
1	5140048-66	BASE	1
2	5140048-67	MOTOR HOUSING	1
3	5140048-68	STATOR	1
4	5140048-69	ROTOR	1
5	5140048-70	SWITCH	1
6	5140048-70	SWITCH	1
7	5140048-72	FAN	1
8	5140048-73	BEARING	2
9	5140048-74	BELL HOUSING	2
10	5140048-75	WASHER	6
11	5140048-76	WASHER	6
12	5140048-77	BOLT	6
13	5140048-78	BUSHING	1
14	5140048-79	WASHER	2
15	5140048-80	SCREW	2
16	5140048-81	GUARD	1
17	5140048-82	WHEEL GUARD	1
18	5140048-83	SCREW	6
19	5140048-84	WHEEL FLANGE	4
20	5140048-85	GRINDING WHEEL	1
21	5140048-86	GRINDING WHEEL	1
22	5140048-87	NUT	1
23	5140048-88	NUT	1
24	5140048-89	RIGHT COVER	1
25	5140048-90	LEFT COVER	1
26	5140048-91	SCREW	6
27	5140048-92	ARM	2

Parts List for 23-725 Type 3

Item Number	Part Number	Description	Qty Required
28	5140048-93	TOOL REST	2
29	5140048-94	BOLT	2
30	5140048-95	WASHER	2
31	5140048-96	WATER TRAY	1
32	5140048-97	SCREW	6
33	5140048-98	HOLDER	1
34	5140048-99	CLAMP	1
35	5140049-00	CAPACITOR	1
36	5140049-01	SWITCH	1
37	5140049-02	SWITCH GUARD	1
38	5140049-03	CLAMP	1
39	5140049-04	CLAMP PLATE	1
40	5140049-05	SCREW	3
41	5140049-06	CORD SET	1
42	5140049-07	WASHER	1
43	5140049-08	COPPER WASHER	1
44	5140049-09	SCREW	1
45	5140049-10	BASE PLATE	1
46	5140049-11	FOOT	4
47	5140049-12	WASHER	2
48	5140049-13	LIGHT ASSEMBLY	1
49	5140049-14	BOLT	2
50	5140049-15	WASHER	4
51	5140049-16	SPARK ARRESTOR	1
52	5140049-17	SPARK ARRESTOR	1
53	5140049-18	SCREW	2
54	5140049-19	WASHER	2

Parts List for 23-725 Type 3

Item Number	Part Number	Description	Qty Required
55	5140049-20	CLAMP	2
56	5140049-21	ROD	1
57	5140049-22	MOUNTING ROD	1
58	5140049-23	BOLT	2
59	5140049-24	NUT	2
60	5140049-25	EYESHIELD	2
61	5140049-26	WHEEL DRESSING TOOL	1
62	5140049-27	BOX-END WRENCH	1
64	5140049-28	ROTATION LABEL	2
65	5140049-29	LABEL	1
66	5140049-30	TERMINAL	2
67	5140049-31	WASHER	4
68	5140049-32	BOLT	4
69	5140049-33	SCREW	2
70	5140049-34	MOTOR	1