




**PW150/PW150-3/4"/PW150R****Parts Reference Guide****Repair Kit****YK0402 (PW150)  
YK0403 (PW150R)****\* Schematic drawings inside**

Senco Products, Inc.  
8485 Broadwell Rd.  
Cincinnati, OH 45244

Questions? Comments? call Senco's toll-free Action-line:  
1-800-543-4596 or e-mail: [toolprof@senco.com](mailto:toolprof@senco.com)






Visit our Website: [www.senco.com](http://www.senco.com)

# PW150/PW150-3/4"/PW150R Senco®



# PW150/PW150-3/4"/PW150R

**SENCO**




## Kits Available

- YK0432 3/4" Guide Body
- YK0436 Double Length Magazine

## Available Plugs

(Not Included with Tool)



## ✓ Recommended Plugs

Plugs shown smaller than actual size

# PW150/PW150-3/4"/PW150R

REPLACEMENT PARTS LIST • LISTA DE PARTES DE REPUESTO • ERSATSTEILE-LISTE • LISTE DE PIÈCES DE RECHANGE

PART NO.	DESCRIPTION	DESCRIPCIÓN	BESCHREIBUNG	DÉSIGNATION
AC0261	CAP	TAPA	KAPPE	BOUCHON
AC0269	SEAL	SELLO	DICHTUNG	JOINT
AC0270	SEAL	SELLO	DICHTUNG	JOINT
AC0271	CAP	TAPA	KAPPE	BOUCHON
AC0272	SHIELD (PW150R)	PLACA	PLATTE	PLAQUE
AC0273	MAIN BODY	CARCASA	GEHÄUSE	CORPS
BB0215	VALVE ASSEMBLY	ASAMBLE DE VÁLVULA	VENTIL-ZUSAMMENBAU	VALVE D'ASSEMBLEE
BC0391	SEAL	SELLO	DICHTUNG	JOINT
BC0392	RETAINER	JUNTA TÓRICA	SICHERUNGSRING	RETENUE
BC0393	RETAINER	JUNTA TÓRICA	SICHERUNGSRING	RETENUE
BC0394	VALVE	VÁLVULA	VENTIL	VALVE
BC0410	CYLINDER	CILINDRO	ZYLINDER	CYLINDRE
BC0411	DEFLECTOR	DESVIADOR	ABWEISER	DÉFLECTEUR
BC0412	STOP	TOPE	PUFFER	ARRÊT
BC0413	SEAL	SELLO	DICHTUNG	JOINT
BC0415	RETAINER	JUNTA TÓRICA	SICHERUNGSRING	RETENUE
CB0037	VALVE ASSEMBLY	ASAMBLE DE VÁLVULA	VENTIL-ZUSAMMENBAU	VALVE D'ASSEMBLEE
EA0152	PISTON ASSEMBLY	ASAMBLE DE PISTON	KOLBEN-ZUSAMMENBAU	ENSEMBLE PISTON-COUTEAU
EC0441	SEAL	SELLO	DICHTUNG	JOINT
FC0477	SHIELD (PW150R)	PLACA	PLATTE	PLAQUE
FC0478	PIN	PASADOR	STIFT	GOUPILLE
FC0479	BRACKET	SOPORTE	HALTERUNG	SUPPORT DE FIXATION
FC0480	GUIDE BODY	PLACA DE NARIZ	KLAMMERFÜHRUNG	FRONT
FC0481	COVER	CUBIERTA	ABDECKUNG	COUVERCLE
FC0482	LATCH	UÑETA	VERSCHLUSS	DOIGT DE RETENUE
FC0501	GUIDE BODY	PLACA DE NARIZ	KLAMMERFÜHRUNG	FRONT
GB0574	RAIL ASSEMBLY (PW150)	ASAMBLE DE CARRIL	SCHIENE-ZUSAMMENBAU	RAIL D'ASSEMBLÉE
GB0575	RAIL ASSEMBLY (PW150R)	ASAMBLE DE CARRIL	SCHIENE-ZUSAMMENBAU	RAIL D'ASSEMBLÉE
GB0576	DOOR ASSEMBLY (US)	ASAMBLE DE PUERTA	ABDECKSCHIEBER-ZUSAMMENBAU	ENSEMBLE PORTE
GB0577	DOOR ASSEMBLY (EU)	ASAMBLE DE PUERTA	ABDECKSCHIEBER-ZUSAMMENBAU	ENSEMBLE PORTE
GB0584	RAIL ASSEMBLY (PW150-3/4)	ASAMBLE DE CARRIL	SCHIENE-ZUSAMMENBAU	RAIL D'ASSEMBLÉE
GC0901	GUIDE	GUÍA	FÜHRUNG	GUIDE
GC0902	RETAINER	JUNTA TÓRICA	SICHERUNGSRING	RETENUE
GC0903	PIN	PASADOR	STIFT	GOUPILLE
GC0904	PIN	PASADOR	STIFT	GOUPILLE
GC0905	BRACKET	SOPORTE	HALTERUNG	SUPPORT DE FIXATION
GC0906	FEEDER SHOE	ALIMENTADOR	NAGELSCHIEBER	POUSSOIR
GC0907	GUIDE (PW150R)	GUÍA	FÜHRUNG	GUIDE
GC0908	GUIDE (PW150R)	GUÍA	FÜHRUNG	GUIDE
GC0909	COVER	CUBIERTA	ABDECKUNG	COUVERCLE
GC0974	FEEDER SHOE	ALIMENTADOR	NAGELSCHIEBER	POUSSOIR
HA0150	TRIGGER ASSEMBLY	ASAMBLE DE GATILLO	AUSLÖSER-ZUSAMMENBAU	ENSEMBLE GÂCHETTE
HA0196	TRIGGER ASSEMBLY	ASAMBLE DE GATILLO	AUSLÖSER-ZUSAMMENBAU	ENSEMBLE GÂCHETTE
HC0382	PIN	PASADOR	STIFT	GOUPILLE
HC0383	SAFETY ELEMENT	SEGURO	SICHERHEITSVORRICHTUNG	PALPEUR DE SÉCURITÉ
HC0384	SAFETY ELEMENT	SEGURO	SICHERHEITSVORRICHTUNG	PALPEUR DE SÉCURITÉ
HC0385	SAFETY ELEMENT	SEGURO	SICHERHEITSVORRICHTUNG	PALPEUR DE SÉCURITÉ
HC0386	GUIDE	GUÍA	FÜHRUNG	GUIDE
HC0387	COVER	CUBIERTA	ABDECKUNG	COUVERCLE
HC0388	SAFETY ELEMENT (PW150R)	SEGURO	SICHERHEITSVORRICHTUNG	PALPEUR DE SÉCURITÉ
HG0185	SAFETY LABEL (US)	ETIQUETA	AUFKLEBER	ÉTIQUETTE
HG0186	SAFETY LABEL (EU)	ETIQUETA	AUFKLEBER	ÉTIQUETTE
KB3459	SCREW	TORNILLO	SCHRAUBE	VIS
KB3570	WASHER (PW150R)	ARANDELA	SCHIBE	RONDELLE
KB3571	WASHER	ARANDELA	SCHIBE	RONDELLE
KB3599	RETAINER	JUNTA TÓRICA	SICHERUNGSRING	RETENUE
KB4352	SPRING	RESORTE	FEDER	RESSORT
KB4354	SPRING	RESORTE	FEDER	RESSORT
KB4355	SPRING	RESORTE	FEDER	RESSORT
KB4356	SPRING	RESORTE	FEDER	RESSORT
KB4357	SPRING	RESORTE	FEDER	RESSORT
KB6588	SCREW (PW150R)	TORNILLO	SCHRAUBE	VIS
KB9825	SCREW	TORNILLO	SCHRAUBE	VIS
KB9826	SCREW	TORNILLO	SCHRAUBE	VIS
KB9827	SCREW (PW150R)	TORNILLO	SCHRAUBE	VIS
KB9828	SCREW	TORNILLO	SCHRAUBE	VIS
KB9829	SCREW	TORNILLO	SCHRAUBE	VIS
KB9830	SCREW	TORNILLO	SCHRAUBE	VIS
KB9831	SCREW	TORNILLO	SCHRAUBE	VIS
KB9833	SCREW	TORNILLO	SCHRAUBE	VIS
KB9835	SCREW	TORNILLO	SCHRAUBE	VIS
KB9837	NUT	TUERCA	MUTTER	ÉCROU
KB9838	WASHER	ARANDELA	SCHIBE	RONDELLE
KB9839	WASHER	ARANDELA	SCHIBE	RONDELLE
KB9841	PIN	PASADOR	STIFT	GOUPILLE
KB9842	PIN	PASADOR	STIFT	GOUPILLE
KB9843	PIN	PASADOR	STIFT	GOUPILLE
KB9844	PIN	PASADOR	STIFT	GOUPILLE
KB9851	WASHER	ARANDELA	SCHIBE	RONDELLE
KB9852	SCREW	TORNILLO	SCHRAUBE	VIS
LB0922	SEAL	SELLO	DICHTUNG	JOINT
LB0923	SEAL	SELLO	DICHTUNG	JOINT
LB0924	SEAL	SELLO	DICHTUNG	JOINT
LB0957	SEAL	SELLO	DICHTUNG	JOINT
LB0958	SEAL	SELLO	DICHTUNG	JOINT
LB0959	SEAL	SELLO	DICHTUNG	JOINT
LB0960	SEAL	SELLO	DICHTUNG	JOINT

Questions? Comments? call SENCO's toll-free Action-line: 1-800-543-4596 (North & South America only) or e-mail: [toolprof@senco.com](mailto:toolprof@senco.com)