



## Parts List for 3338 Type 2

Item Number	Part Number	Description	Qty Required
1	869074-02	ARMATURE	1
2	868405-02	FIELD	1
3	868128-00	SWITCH	1
4	940146-01	BRUSH	2
5	330078-98	CORD/10 FT/16-2	1
6	761202-00	HOLDER,BRUSH	2
7	761203-00	CLAMP	2
8	605040-23	BALL BEARING	1
9	868132-03	BEARING,BALL	1
9	868132-03	BEARING,BALL	1
9	868132-03	BEARING,BALL	1
10	868129-09	LEAD	1
11	868145-00	LEVER,SWITCH	1
12	761209-00	SCREW	1
13	868123-00	ACTUATOR,SWITCH	1
14	000000-00	No Longer Available	1
15	949896-12	SCREW	4
16	000000-00	No Longer Available	1
17	860079-03	CIRCLIP	1
18	249220-00	SCREW	4
19	868520-00	CORD PROTECTOR	1
20	000000-00	No Longer Available	4
21	930248-00	WASHER	4
22	000000-00	No Longer Available	4
23	248611-00	CLAMP,CORD	1
24	868129-10	LEAD	1
26	000000-00	No Longer Available	1

## Parts List for 3338 Type 2

Item Number	Part Number	Description	Qty Required
27	000000-00	No Longer Available	1
28	868124-01	LENS	1
29	000000-00	No Longer Available	4
30	761225-02	NUT	1
31	000000-00	No Longer Available	1
32	942902-01	BAFFLE	1
33	N041821	FAN	1
34	868127-00	WASHER	1
35	942906-00	LEVER,CLAMP	1
36	942930-00	LOCK,SPINDLE	1
37	942909-00	SPRING	1
38	868204-00	SCREW	1
39	942908-00	PIN	1
40	000000-00	No Longer Available	2
41	869355-00	REPAIR KIT	1
42	942898-00	HOUSING,LOWER	1
43	942918-02	SCALE	1
44	868150-00	NUT	1
45	942910-00	SUPPORT	1
46	868122-00	RACK	1
47	000000-00	No Longer Available	1
48	761243-05	PINION	1
49	869355-00	REPAIR KIT	1
50	868119-00	PLATE	1
51	939840-05	SCREW,WING	1
52	942912-00	SPRING	1
53	000000-00	No Longer Available	1

## Parts List for 3338 Type 2

Item Number	Part Number	Description	Qty Required
54	942911-00	LOCK	1
55	000000-00	No Longer Available	1
56	942900-03	CLAMP	1
57	249424-02	SCREW	3
58	942901-00	NUT	1
59	868116-01	COLLET	1
60	942893-01	COLLET NUT	1
61	868115-00	SPRING	2
62	868566-01	ROD	2
63	868124-01	LENS	1
64	761258-00	SPRING	1
65	868125-00	SCREW	1
66	249432-00	SCREW	1
67	942931-02	SCREW	1
68	330015-04	NUT,HEX	3
69	942931-01	SCREW	1
70	761264-00	SPRING	1
71	942931-01	SCREW	1
72	000000-00	No Longer Available	1
73	720664-00	BALL	1
74	868082-00	SPRING	1
75	249412-20	SCREW	2
76	868151-00	BUSHING,GUIDE	1
77	942904-00	SPRING	1
78	329820-49	PLATE,BASE	1
78	98014-40	SCREW	3
79	940459-00	BASE,SUB	1

## Parts List for 3338 Type 2

Item Number	Part Number	Description	Qty Required
80	868147-01	ROD	2
81	326573-01	SCREW,WING	5
82	942915-00	FACE,GUIDE	2
83	000000-00	No Longer Available	1
84	860073-01	WASHER	4
85	868142-02	PC BOARD	1
86	000000-00	No Longer Available	1
87	000000-00	No Longer Available	1
88	868141-00	POLE PIECE	1
89	248978-00	WAVY WASHER	4
90	868129-07	LEAD	1
91	000000-00	No Longer Available	1
92	249424-21	SCREW	5
93	761287-00	WRENCH 8 MM	1
94	000000-00	No Longer Available	1
95	000000-00	No Longer Available	1
96	233304-00	NAMEPLATE-SHEET	1
97	868082-00	SPRING	2
98	860205-04	SCREW	6
99	942916-00	HOLDER,GUIDE	1
114	868127-01	SPACER	1