


## Band Saw - F 012 338 500 - 3385

Item	Part Number	Description	Illustration	Price	Quantity	Price Group
7	2 610 958 799	Ball Bearing	1	-,-	4	-
10	2 610 958 800	Wheel	1	-,-	2	-
13	2 610 958 801	Alarm Switch	1	-,-	1	-
29	2 610 958 802	Knob	1	-,-	1	-
30	2 610 958 803	Rod	1	-,-	1	-
43	2 610 958 805	Light-Emitting-Diode	1	-,-	1	-
47	2 610 958 806	Bolt	1	-,-	4	-
49	2 610 958 809	Ball Bearing	1	-,-	2	-
71	2 610 958 810	Belt	1	-,-	1	20
72	2 610 958 811	Brush	1	-,-	1	-
73	2 610 958 812	Latch	1	-,-	1	-
75	2 610 958 813	Toggle Switch	1	-,-	1	-
76	2 610 958 814	Toggle Switch	1	-,-	2	-
77	2 610 958 815	Latch	1	-,-	1	-
82	2 610 958 816	Knob	1	-,-	1	-
83	2 610 958 817	Laser	1	-,-	1	-
84	2 610 958 818	Clamp	1	-,-	1	-
101	2 610 958 819	Insert	1	-,-	1	-
104	2 610 958 820	Pan head screw	1	-,-	1	-
105	2 610 958 821	Cord	1	-,-	1	-
106	2 610 958 822	Nut	1	-,-	1	-
109	2 610 958 823	Transformer	1	-,-	1	32
111	2 610 958 824	Grommet	1	-,-	2	-
889	2 610 958 825	Mitre Fence	1	-,-	1	-
898	2 610 958 826	Guide	1	-,-	1	-

Illustration - Type E



Information subject to change without further notice.