







## Parts List for 36-980 Type 1

Item Number	Part Number	Description	Qty Required
1	1313270	PUSH NUT	1
2	1313271	PIN	1
3	A06457	GUARD ASSY	1
3	A06320	GUARD	1
4	1313273	PIN	1
5	1313274	BRACKET	1
6	1313275	LOCK RING	1
7	1313276	SPRING	1
8	901110231476S	BOLT	1
9	1344975	SPLITTER	1
10	A06314	BRACKET	1
11	904010101620S	WASHER	1
12	902010101300S	HEX NUT	1
13	901010600626S	CAP SCREW	1
14	491957-00	LOCK WASHER	2
15	904010312934S	WASHER	2
16	330016-02	WASHER,PLAIN	2
17	901030100755S	CAP SCREW	1
18	901030100230S	SCREW	1
19	A06331	BRACKET	1
20	1344977	PLATE	1
21	901010600649S	CAP SCREW	1
22	912856	WING	1
23	904010101606S	STEEL WASHER	6
24	904020101716	LOCK WASHER	6
25	901010600664S	CAP SCREW	6
26	1346470	SET SCREW	2

## Parts List for 36-980 Type 1

Item Number	Part Number	Description	Qty Required
27	A06307	TABLE	1
28	901044615297	SCREW	4
29	A06327	TABLE INSERT	1
30	1246047	MACH SCREW	1
31	491889-00	SCREW HEX HEAD	2
35	1313279	ANTI-KICKBACK FINGER	2
36	1310311	ROLL PIN	1
37	A01413	WING	1
38	A14330	WARNING LABEL	1
46	1352011	SCREW	1
51	34-928	MITER GAUGE	1
69	1344602	POWER CORD	1
70	1344609	SWITCH BOX	1
71	901030308013S	SCREW	1
72	438010170206S	SWITCH	1
73	1344601	SWITCH PADDLE	1
74	1344608	SWITCH PLATE	1
75	901051631126S	SCREW	2
76	1310210	LOCKWASHER	4
77	A14212	CORD W/FEMALE DISCON	1
78	1344607	SWITCH BOX	1
79	A14433	SCREW	3
80	1340406	SCREW	1
81	489026-00	HEX NUT	1
82	489191-00	HEX NUT	1
83	904020201704S	LOCK WASHER	1
84	904010101615	STEEL WASHER	1

## Parts List for 36-980 Type 1

Item Number	Part Number	Description	Qty Required
89	A06464	BEVEL SCALE	1
100	A13154	CABINET	1
101	000000-00	No Longer Available	1
103	1347527	SCREW	3
104	904010101620S	WASHER	4
105	A12585	BRACKET	1
106	489047-00	CAP SCREW	4
107	1342930	CLAMP	3
108	1343545	WASHER	7
109	1243569	NUT	3
110	1234908	INSULATOR	1
111	A13736	WARNING LABEL	1
112	422350600001S	WRENCH HOOK	1
113	A08150	SCREW	2
200	A06325	ARBOR NUT	1
201	1344991	FLANGE	1
202	A06328	ARBOR SHAFT	1
203	1086894S	BEARING	2
204	928060207382S	LOAD SPRING	1
205	1344994	SHAFT	1
206	1344993	SPACER	1
207	A06311	BRACKET	1
208	1344933	SCREW	2
210	1344996	BEARING CLOSURE NUT	1
211	1344997	SPACER	1
212	1344998	PULLEY HALF	2
213	902010201226S	NUT	1

## Parts List for 36-980 Type 1

Item Number	Part Number	Description	Qty Required
214	1345000	BRACKET	1
215	904100313810	STEEL WASHER	4
216	1343390	SPRING WASHER	4
217	A09163	SCREW	4
218	902012831393	LOCK NUT	4
219	A12691	TRUNNION	1
220	651195-00	MOTOR ASSEMBLY	1
221	A08148	KEY	1
222	1345008	MOTOR PULLEY	1
223	901041500206	SET SCREW	1
224	49-034	BELT	1
225	5140081-98	SCREW	1
227	A13326	MOTOR COVER	1
228	904010312934S	WASHER	1
229	1345006	SPACER	1
230	489026-00	HEX NUT	1
231	A12692	COVER	1
232	904030301757S	LOCK WASHER	4
233	902040101402	WING NUT	1
234	902010101300S	HEX NUT	4
235	904030301656S	LOCK WASHER	4
236	904010101620S	WASHER	4
237	1345003	MOTOR PLATE	1
240	1345001	PIN	2
241	1345002	SPRING	1
243	1344989	TIE BAR	2
244	1313289	WASHER	1

## Parts List for 36-980 Type 1

Item Number	Part Number	Description	Qty Required
245	902010201226S	NUT	1
246	1344988	ELEVATING SHAFT ASSY	1
247	000000-00	No Longer Available	2
248	1243339	SCREW	1
249	1344933	SCREW	1
250	A06309	FRONT TRUNNION	1
251	1344986	SLEEVE	1
252	1344981	SPACER	1
253	A06315	BRACKET	1
254	1310062	WASHER	1
255	A06462	SCREW	1
256	A06375	HANDWHEEL ASSY	2
257	1313239	WASHER	2
258	651140-00	KNOB	2
259	A07810	CURSOR	1
260	000000-00	No Longer Available	2
261	1344984	TILT SHAFT ASSY	1
262	1344983	ECCENTRIC	1
263	488808-00	LOCK WASHER	3
265	1345086	SHIM	7
266	491950-00	SET SCREW	4
267	A06373	BRACKET	1
268	1345084	JAM NUT	1
269	489192-00	FIBER WASHER	2
270	1344985	COLLAR	2
271	902015031514	FLANGED HEX NUT	2
272	1344604	BRACKET	1



## Parts List for 36-980 Type 1

Item Number	Part Number	Description	Qty Required
273	901020100506	MACHINE SCREW	2
277	884298	HEX WRENCH (4MM)	1
278	1313232	WRENCH	1
279	955010501482	WRENCH	1
301	A13219	DUST CHUTE	1
302	A12359	FRONT PANEL	2
303	A12140	LEG	4
304	A12360	SIDE PANEL	2
305	A12571	SUPPORT	1
306	A12885	WHEEL BRACKET	1
307	A12142	SUPPORT	2
308	A16341	SUPPORT	1
309	A12852	FOOT PAD	2
310	651026-00	FOOT	1
311	436021000001	WHEEL - 5/16 ID	2
312	901030108024	CAP SCREW	2
313	1342922	LOCK NUT	3
314	436020480009S	LEVELING SCREW	2
315	902010205435S	JAM NUT	4
316	651027-00	WHEEL ASSEMBLY	1
317	1246034	CAP SCREW	3
318	330016-03	WASHER,PLAIN	8
319	429898-05	LOCKWASHER,M8	5
320	330015-03	NUT,HEX	3
321	901110231476S	BOLT	12
322	A13496	SCREW	50
325	902015031865S	NUT	57

## Parts List for 36-980 Type 1

Item Number	Part Number	Description	Qty Required
326	436023670005	FOOT LEVER ASSY	1
327	436020710001	PIN	1
328	904010101636S	WASHER	2
329	651027-00	WHEEL ASSEMBLY	1
330	901010631537	SCREW	1
331	904150120052	RETAINER	2
340	A12851	WHEEL BRACKET	1
846	A19353	HARDWARE BAG	1
846	A19288	HARDWARE PACK	1