



## Parts List for 380 Type 2

Item Number	Part Number	Description	Qty Required
1	616573-00SV	ARMATURE & BRGS	1
2	615795-00SV	FIELD	1
4	445861-34	BRUSH	2
5	445860-00	SPRING,BRUSH	2
6	449899-05	RING,BRUSH	1
7	656494-00	SWITCH	1
8	330072-98	CORD/8FT/18-2SJ	1
9	605040-05	BEARING, BALL	1
10	330003-17	BEARING,BALL	1
11	098012-11	MACH SCREW	1
12	330019-02	SCREW,PLASTITE	4
13	464285-00	SCREW	4
14	330019-13	SCREW,PLASTITE	7
15	N110362	BALL BEARING	1
16	464281-00	FAN	1
17	330019-08	SCREW	2
19	N517310	CLAMSHELL SET	1
20	825209-00	TERMINAL	2
21	330005-01	PROTECTOR,CORD	1
22	380414-00	CLAMP,CORD	1
23	N517315	CAP	1
24	144964-00	SHROUD	1
25	144988-02	FOOT	2
26	148712-01	PLATEN	1
27	151284-00SV	PAD	1
28	151288-00	CLAMP,PAPER	2
29	151652-00	WASHER,CONE	1

## Parts List for 380 Type 2

Item Number	Part Number	Description	Qty Required
31	144974-00	SEAL,DUST	1
34	144989-00	LEAD ASSY.	1
36	144956-00	NUT	2
39	445964-00	TERMINAL	2
40	N538032	RATING LABEL	1
43	151669-00	RING,RETAINING	1
50	144954-00	PUNCH,PAPER	1
51	608358-00	DUST BAG	1
52	N058185	WARNING LABEL	1
53	N063101	WARNING LABEL	1