

380BTS, 380BFS

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos


Reservdelar

A 380BTS, 380BFS




Pos.	Compl No.	Part No.	Quantity	Notes
1		505 18 08-01	1	
2		505 17 98-01	1	
3		505 18 09-01	1	
4		544 27 41-01	1	
5		544 27 40-01	1	
6		505 18 11-01	1	
7		544 27 38-01	2	
8		505 18 13-01	1	
9		544 27 60-01	1	

B1 380BTS




Pos.	Compl No.	Part No.	Quantity	Notes
1		505 18 14-01	1	
2	1	575 99 37-01	1	
3	2	537 22 62-01	1	
4	2	537 22 63-01	1	
5	2	505 18 17-01	1	
6	2	505 18 18-01	1	
7	2	505 18 19-01	1	
8	1	503 21 66-18	2	
9	1	502 24 49-01	1	
10	1	505 29 08-01	1	
11	1	735 58 35-01	1	
12	1	505 18 15-01	1	
13	1	537 37 39-01	1	
14	1	502 24 55-01	1	
15	1	503 21 29-06	1	
16	1	502 24 60-01	1	
17	1	537 17 42-01	1	
18	1	502 24 54-01	1	
19	1	505 56 79-01	1	
20	1	502 24 48-01	1	
21	1	502 64 17-01	1	
22	1	537 14 12-03	1	
23	1	503 22 10-13	1	
24	1	502 24 53-01	1	
25	1	503 22 65-04	1	
26	1	544 27 59-01	1	
27	1	504 80 03-01	1	
28	1	725 23 44-51	1	


B2 380BFS



18




Pos.	Compl No.	Part No.	Quantity	Notes
1		544 27 62-01	1	
2	1	544 27 63-01	1	
3	1	544 27 74-01	1	
4	1	544 27 71-01	1	
5	1	544 27 70-01	1	
6	1	544 27 69-01	1	
7	1	544 27 72-01	1	
8	1	544 36 58-01	2	
9	1	544 27 67-01	1	
10	1	544 27 65-01	1	
11	1	544 27 64-01	1	
12	1	544 27 66-01	1	
13	1	544 27 72-01	1	
14	1	544 27 68-01	1	
15	1	544 27 73-01	1	
16	1	544 27 75-01	1	
17	1	544 27 76-01	1	
18		544 27 77-01	1	
19	18	503 20 07-45	1	
20	18	537 17 28-01	1	
21	18	537 17 29-01	1	
22	18	731 23 14-01	1	
23	18	537 26 02-01	1	
24	18	503 22 65-04	1	
25	18	544 27 59-01	1	
26	18	502 20 40-01	1	
27	18	725 23 44-51	1	



Page C
380BTS, 380BFS

Pos.	Compl No.	Part No.	Quantity	Notes
1		505 18 20-01	1	
2		544 26 36-01	4	
3		544 36 34-01	1	
4		505 18 21-01	1	

D 380BTS, 380BFS



Husqvarna
380BTS
E-tech II

17A


Husqvarna
380BFS
E-tech II

17B

Page D
380BTS, 380BFS

Pos.	Compl No.	Part No.	Quantity	Notes
1		544 26 27-01	1	
2	1	544 26 30-01	2	
3	1	544 26 29-01	2	
4	1	544 26 28-01	2	
5		544 26 10-01	1	
6	5	544 26 13-01	1	
7	5	544 26 17-01	1	
8	5	544 26 20-01	1	
9	5	544 26 19-01	1	
10	5	544 26 18-01	1	
11	5	544 26 11-01	1	
12	5	544 26 12-01	1	
13	5	544 26 16-01	1	
14	5	544 26 15-01	1	
15	5	544 26 14-01	1	
16	5	544 26 31-01	4	
17A		504 79 58-02	1	380BTS
17B		504 79 59-02	1	380BFS


E 380BTS, 380BFS



Page E
380BTS, 380BFS


Pos.	Compl No.	Part No.	Quantity	Notes
1		505 18 22-01	1	
2	1	505 18 23-01	2	
3	1	544 27 13-01	1	
4	1	544 26 36-01	2	
5		544 27 16-01	1	
6		544 27 15-01	1	
7		544 27 20-01	4	
8		505 18 25-01	1	
9		505 18 26-01	4	
10		505 18 29-01	1	
11		544 26 32-01	2	
12		544 25 71-01	1	
13		544 25 69-01	1	
14		544 25 72-01	1	
15		544 26 38-01	1	
16		544 25 70-01	4	
17	27	505 18 31-01	1	
18		544 26 36-01	3	
19		544 26 33-01	1	
20	19	544 26 34-01	1	
21	19	544 26 35-01	2	
22		544 27 19-01	1	
23		544 26 37-01	1	
24		505 18 28-01	1	
25		544 27 19-01	1	
26		505 18 24-01	1	
27		505 18 30-01	1	
28	27	505 18 32-01	1	

F 380BTS, 380BFS



Page F
380BTS, 380BFS

Pos.	Compl No.	Part No.	Quantity	Notes
1		504 79 61-01	1	
2		504 79 84-01	2	
3		544 25 80-01	1	
4		504 79 60-01	1	
5	4	504 79 82-01	1	
6	4	504 79 83-01	1	
7	4	544 36 27-01	4	




Page G
380BTS, 380BFS

Pos.	Compl No.	Part No.	Quantity	Notes
1A		505 18 33-01	1	EU
1B		505 18 34-01	1	US
2	1	544 27 28-01	1	
3	1	544 27 29-01	1	
4	1	544 27 30-01	1	
5	1	504 11 77-01	1	
6	1	504 11 79-01	1	
7	1	544 27 26-01	1	
8	1	544 27 24-01	1	
9	1	544 27 25-01	1	
10		544 27 32-01	1	
11		544 27 31-01	3	


Page H
380BTS, 380BFS

Pos.	Compl No.	Part No.	Quantity	Notes
1		544 25 99-01	1	
2		544 26 00-01	1	
3		544 26 01-01	1	
4		505 18 35-01	1	
5	4	544 26 05-01	1	
6	4	544 26 03-01	1	
7	4	505 18 36-01	1	
8	4	544 26 06-01	1	
9	4	544 26 09-01	1	
10		544 36 29-01	1	
11		544 25 75-01	2	
12		505 18 37-01	1	
13		544 25 90-01	1	
14		544 25 89-01	1	

J**380BTS, 380BFS**


Page J
380BTS, 380BFS

Pos.	Compl No.	Part No.	Quantity	Notes
1		544 25 68-01	2	
2		505 18 38-01	1	
3		544 25 66-01	4	
4		504 79 62-01	1	
5		544 25 65-01	1	
6		505 18 39-01	1	
7		544 25 76-01	2	
8		505 18 40-01	1	
9		544 25 75-01	4	



Page K
380BTS, 380BFS



Pos.	Compl No.	Part No.	Quantity	Notes
1		544 25 88-01	4	
2	1	544 25 86-01	1	
3	1	544 25 87-01	2	
4	1	544 25 82-01	1	
5		544 25 83-01	1	
6		544 25 84-01	2	
7		544 25 85-01	1	
8		544 25 91-01	6	



Page L
380BTS, 380BFS

Pos.	Compl No.	Part No.	Quantity	Notes
1		504 79 65-01	2	
2		504 79 63-01	1	
3		504 79 64-01	1	
4		544 25 95-01	2	
5		544 25 96-01	1	
6		544 25 97-01	2	
7		544 26 00-01	1	
8		544 25 98-01	1	

M 380BTS, 380BFS




Page M
380BTS, 380BFS

Pos.	Compl No.	Part No.	Quantity	Notes
1		544 26 43-01	3	
2		505 18 43-01	1	
3		544 26 46-01	2	
4		544 26 36-01	11	
5		505 18 41-01	1	
6		544 26 51-01	2	
7		505 18 44-01	1	
8		544 26 47-01	2	
9		504 12 23-01	1	BT
10		544 26 36-01	6	
11		544 26 49-01	1	
12		544 26 43-01	1	
13		505 18 42-01	1	
14		505 18 45-01	2	

N1


380BTS, 380BFS



Page N1
380BTS, 380BFS


Pos.	Compl No.	Part No.	Quantity	Notes
1		505 18 46-01	1	
2		505 18 47-01	4	
3		505 18 48-01	1	
4		544 27 02-01	6	
5		544 27 09-01	2	
6		505 18 49-01	2	
7		544 27 07-01	1	
8		502 85 05-01	1	
9		544 27 05-01	1	
10		544 27 10-01	2	
11		505 18 50-01	1	BT
12		505 18 50-02	1	BF

N2 380BTS, 380BFS



Page N2
380BTS, 380BFS


Pos.	Compl No.	Part No.	Quantity	Notes
1		505 18 51-01	1	
2	1	544 26 97-01	2	
3		505 18 53-01	1	
4		505 18 54-01	1	
5		544 26 43-01	6	
6		505 18 52-01	1	
7		544 26 43-01	1	



Page P
380BTS, 380BFS

Pos.	Compl No.	Part No.	Quantity	Notes
1		505 18 56-01	1	
2		544 27 00-01	2	
3		505 18 55-01	1	
4		544 26 97-01	2	
5		544 27 45-01	1	
6		544 27 46-01	1	



Q 380BTS, 380BFS




Page Q
380BTS, 380BFS

Pos.	Compl No.	Part No.	Quantity	Notes
1		505 18 31-01	1	
2	1	544 36 35-01	1	
3	1	544 36 47-01	2	
4	1	544 36 48-01	1	
5	1	544 36 49-01	1	
6	1	544 36 50-01	1	
7	1	544 36 41-01	1	
8	1	544 36 40-01	1	
9	1	544 36 42-01	1	
10	1	544 36 54-01	1	
11	1	544 36 53-01	1	
12	1	544 36 43-01	1	
13	1	544 36 44-01	1	
14	1	544 36 45-01	1	
15	1	504 64 31-01	1	
16	1	544 36 46-01	1	
17	1	544 36 39-01	1	
18	1	544 36 38-01	1	
19	1	544 36 52-01	4	
20	1	544 36 51-01	1	

R 380BTS, 380BFS
Accessories
Zubehöre
Accessoires
Accesorios
Tillbehör



2



Page R
380BTS, 380BFS

Pos.	Compl No.	Part No.	Quantity	Notes
1		544 27 44-01	1	
2		544 40 00-01	1	
3	2	537 24 13-01	1	
4	2	537 29 29-01	1	
5	2	544 27 59-01	1	
6	2	502 20 40-01	1	
7	2	725 23 47-51	1	
8	2	725 53 25-55	1	
9	2	731 23 14-01	2	
10	2	537 17 29-01	1	
11	2	537 17 28-01	1	
12	2	503 20 02-45	1	
13	2	731 23 14-01	1	
14		544 27 48-01	1	