

385, 385 EPA

Spare parts

Replaces

Ersatzteile

Ersetzt

Pièces détachées

Remplace

Reserve onderdelen

Vervangt

Repuestos


Reemplaza

Reservdelar


Ersätter

106 27 41-61

A




B



C *compl 537 00 07-01 Std
 **compl 537 00 07-02 Hd


*537 00 09-01 Std
 **537 00 10-01 Hd



503 98 74-01* **

* **503 20 44-26 (x3)


* **




537 13 72-01* **

537 01 65-01* **

* **503 74 01-02 (x4)



537 06 96-01* **




537 07 23-01* **

D *compl 537 16 97-71

725 53 33-55 (x4)
 503 71 53-01

503 23 51-08
 RCJ 7Y

537 08 62-01



537 00 57-01 ①

503 77 59-01 ①

503 28 90-37 (x2)

737 44 13-00 (x2)

*compl 537 16 98-71




503 25 61-01

E *compl 503 99 34-73

503 26 14-01


*503 25 12-01

503 25 61-01*



*738 22 03-25

F compl 503 95 90-01 FG
 compl 503 95 90-03 Jungle
 *compl 503 95 90-04 DF





724 12 87-59*

503 76 64-02*

725 53 70-55 (x2)


503 76 65-03
 503 20 02-16 (x2)

503 20 06-08 (x2)




503 95 91-01 Tube




G




H

*compl 503 99 11-72




J***compl 537 00 03-71****K****compl 503 98 66-71****L*****compl 503 98 67-71**
***compl 503 98 67-02 (G)**

M




N



P


compl 503 28 04-13
503 28 04-11 EPA

Tilotson HS 299A Tilotson HS 296A EPA

**Q**


Accessories Zubehöre Accessories Tillbehör

*compl 503 55 85-02



WINTER KIT

compl 537 04 38-01



*503 62 12-01

