


11.0 Replacement parts

Replacement parts are listed on the following pages. To order parts or reach our service department, call 1-800-274-6848 Monday through Friday (see our website for business hours, www.waltermeier.com). Having the Model Number and Serial Number of your machine available when you call will allow us to serve you quickly and accurately.

11.1.1 Model J-4200A Belt and Disc Sander Assembly – Exploded View




11.1.2 Model J-4200A Belt and Disc Sander Assembly – Parts List

Index No	Part No	Description	Size	Qty
1.....	J-5508427.....	Bracket.....		1
2.....	5511833.....	Square Nut.....	M10.....	1
3.....	5051081.....	Spring.....		1
4.....	5051091.....	Sleeve.....		1
5.....	5051131.....	Collar		1
6.....	5508431.....	Shaft with Collar		1
7.....	J-5051151.....	Cap		1
8.....	TS-2361051.....	Lock Washer	M5.....	2
9.....	TS-1513051.....	Socket Head Flat Screw	M5x25.....	2
10.....	5051721.....	Hand Wheel		1
12.....	TS-1550071.....	Flat Washer.....	M10.....	2
13.....	J-5508432.....	Tilting Table.....		1
14.....	5508450.....	Hand Knob		4
15.....	5508429.....	Belt Adjustment Knob	M10.....	1
16.....	5511824.....	Drive Screw.....	Ø2x5	5
17.....	5508437.....	Stop Lock		1
18.....	5511828.....	Groove Pin	Ø5x45	1
19.....	5051351.....	Tilting Scale.....		1
20.....	TS-1523011.....	Socket Set Screw	M6x6	2
21.....	5511827.....	Groove Pin	Ø4x8	2
22.....	5051331.....	Segment.....		1
23.....	5511725.....	4200 Arbor Pulley		1
24.....	TS-1504061.....	Socket Head Cap Screw.....	M8x30	4
25.....	TS-2361081.....	Lock Washer	M8.....	4
26.....	J-5508433.....	Trunnion.....		1
27.....	TS-1550061.....	Flat Washer.....	M8.....	9
28.....	TS-2361081.....	Lock Washer	M8.....	9
29.....	TS-1490041.....	Hex Cap Screw	M8x25	3
30.....	5508435.....	Stud	M10.....	1
31.....	TS-1550071.....	Flat Washer.....	M10.....	4
32.....	5508436.....	Acorn Nut and Handle		1
33.....	TS-2361061.....	Lock Washer	M6.....	3
34.....	TS-1482031.....	Hex Cap Screw	M6x16	3
35.....	5508439.....	Preload Bushing	M54	1
36.....	BB-6205ZZ.....	Ball Bearing.....	6205ZZ	1
37.....	J-5508438.....	Bearing Housing		1
38.....	TS-2210951.....	Hex Cap Screw	M10x140	2
39.....	5051421.....	Key	5x5x70 mm.....	1
40.....	5508441.....	Drive Shaft		1
41.....	5051451.....	Key	5x5x35 mm.....	1
42.....	4200A-042.....	Key	5x5x55 mm.....	1
43.....	BB-6204ZZ.....	Ball Bearing	6204ZZ	1
44.....	5051471.....	Retaining Ring	S20	1
45.....	VB-A59.....	V-Belt	17610	1
46.....	TS-2245081.....	Socket Head Flat Screw	M5x8	4
47.....	J-5508444.....	Belt Guard Assembly		1
49.....	TS-1540071.....	Hex Nut, Full	M10.....	5
50.....	5508446.....	Stop Pin		1
51.....	J-5508447.....	Base		1
52.....	TS-2210801.....	Hex Cap Screw	M10x80	4
53.....	TS-1550071.....	Flat Washer.....	M10.....	8
54.....	TS-2361101.....	Lock Washer	M10.....	6
55.....	5051841.....	Garnet Belt		1
56.....	J-5508455.....	Deflector Plate		1
57.....	TS-2361051.....	Lock Washer	M5.....	2

Index No	Part No	Description	Size	Qty
58	TS-1513021	Socket Head Flat Screw	M5x12	2
59	J-5508454	Drive Drum Guard		1
60	5508456	Dust Deflector.....		1
61	TS-2361101	Lock Washer	M10.....	3
62	TS-1491021	Hex Cap Screw	M10x20	3
63	J-5508457	Platen.....		1
64	TS-1514011	Socket Head Flat Screw	M6x12	2
65	J-5051601A	Side Guard.....		1
66	TS-1540231	Hex Nut.....	M24x18	1
67	9058121	Lock Washer, Ext	M24.....	1
68	5051981	Spacer.....		1
69	5051971A	Drive Drum		1
70	5508458	Clamp Ring		1
71	5544728	Drum Spacer.....		2
72	5051031	Tension Lever Pin.....		1
73	5051021	Belt Tension Lever.....		1
74	BB-6202ZZ	Ball Bearing.....	6202ZZ	2
75	5508461	Idler Drum Shaft with Lock Nut		1
76	TS-2342121	Nylon Lock Hex Nut.....	M12.....	2
77	5508460	Bearing Lock Nut.....		1
78	J-5051591A	Idler Drum Guard.....		1
79	5508462	Stud		3
80	5508463	Clamp Bar		2
81	J-5052121	Bottom Guard.....		1
82	TS-2361061	Lock Washer	M6.....	4
83	5052061B	Idler Drum Spacer		2
84	J-5508459	Idler Pin Bracket		1
85	TS-0367061	Roll Pin.....	1/4"x1-1/4"	2
86	5052001	Block		2
87	5052061A	Idler Drum		2
88	5508434	Pointer.....		1
89	5508451	Clamp with Pins.....		2
90	4200A-090	Roll Pin.....	Ø6x45	4
91	J-5508453	Disc Guard		1
92	TS-2239551	Socket Head Cap Screw.....	M10x55	2
93	5051741	Pointer.....		1
94	TS-1523031	SHSS	M6x10	2
95	5051641	Disc, Aluminum		1
96	5051631	Garnet Disc		1
97	5051681	Trunnion.....		2
98	TS-1490041	Hex Cap Screw	M8x25	4
99	J-5508449	Table		1
100	5051701	Tilting Table Scale		1
101	5052271	Deluxe Miter Gauge		1
102	TS-1550071	Flat Washer.....	M10.....	2
103	TS-1482032	Hex Cap Screw	M6x16	4
104	4200A-104J	JET Logo Plate.....		1
105	4200A-105	Label, Direction		2
106	TS-1482081	Hex Cap Screw	M6x40	2
107	TS-1540041	Hex Nut, Full	M6.....	2
108	TS-1523021	Socket Head Flat Screw	M6x8	1
111	5511818	Flat Head Screw	M5x6	4
113	4200A-113	Sponge.....	300x7.5mm, t=2mm....	2


11.4.1 Base Assembly: All 1 Phase Models – Exploded View



11.4.2 Base Assembly: All 1 Phase Models – Parts List

Index No	Part No	Description	Size	Qty
1.....	J-5511743.....	Enclosure		1
2.....	TS-1490031	Hex Cap Screw	M8x20	7
3.....	TS-1550061	Flat Washer	M8	7
4.....	TS-2361081	Lock Washer	M8	7
5.....	TS-1540061	Hex Nut	M8	7
6.....	5511753.....	Tapping Bolt w/Washer		2
7.....	TS-2284082	Pan Head Screw	M4x8	2
8.....	4200A-B335.....	Switch Cover		1
9.....	5514703.....	Switch Box		1
10.....	TS-1490011	Hex Cap Screw	M8x12	4
11.....	TS-2361081	Lock Washer	M8	4
12.....	TS-1550061	Flat Washer	M8	4
13.....	4200A-B336	Motor Cord	1PH	1
14.....	9139391.....	Switch		1
15.....	TS-2360121	Flat Washer	M12	4
16.....	TS-1540081	Hex Nut	M12	4
17.....	5511745.....	Adjustable Mount		4
18.....	4200A-418	Strain Relief Bushing	6N3-4	1
19.....	4200A-B320	Cover		1
20.....	4200A-B321	Pan Head Bolt w/Flange		3
21.....	TS-1540041	Hex Nut	M6	3
22.....	9133081.....	Power Cord	1PH	1
23.....	TS-1540031	Hex Nut	M5	2
24.....	TS-0733203	Lock Washer, Ext	M5	2
25.....	4200A-B325	Pan Head Screw	M5X8	2
26.....	TS-2361041	Lock Washer	M4	4
27.....	JETLOGO-1.....	JET Logo	2-3/4"x8"	1
28.....	TS-1533052	Pan Head Screw	M5x16	1
29.....	4200A-B330	Cord Clamp		1
30.....	TS-1540031	Hex Nut	M5	1
31.....	4200A-B332	Wiring Nut		2
32.....	TS-1550021	Flat Washer	M4	6
33.....	4200A-B334	Label, Voltage		1
34.....	J-5514650.....	Motor	1-1/2HP 115/230V 1Ph	1
35.....	5512937.....	Key	5x5x35 mm	1
36.....	4200A-436	Motor Pulley		1
37.....	TS-1523011	Socket Set Screw	M6x6	1
38.....	TS-1533042	Pan Head Screw	M5X12	2
39.....	4200A-439	Strain Relief Plate		1
40.....	J-5511729.....	Large Cover		1
41.....	J-5052431.....	Motor Mounting Plate		1
	9145531.....	Machine Safety Label (not shown)		1

11.5.1 Base Assembly: All 3 Phase Models – Exploded View



11.5.2 Base Assembly: All 3 Phase Models – Parts List

Index No	Part No	Description	Size	Qty
1.....	4202A-501	Enclosure		1
2.....	TS-1490031	Hex Cap Screw	M8x20	7
3.....	TS-1550061	Flat Washer	M8	11
4.....	TS-2361081	Lock Washer	M8	11
5.....	TS-1540061	Hex Nut	M8	7
6.....	4202A-506	Switch Seat		1
7.....	4202A-507	Pan Head Screw w/Flange	M8x12	2
8.....	TS-1532042	Pan Head Screw	M4x12	2
9.....	4202A-509	Magnetic Switch Assembly	1.5HP	1
9-1.....	4202A-5091	Power Cord	3Ph	1
9-2.....	4202A-5092	Motor Cord	3Ph	1
9-3.....	4202A-5093	Strain Relief	PG13.5	2
9-4.....	4202A-5094	Magnetic Switch	1.5HP/230V/3PH	1
9-4.....	4202A-5095	Magnetic Switch	1.5HP/460V/3PH	1
10.....	TS-1490011	HHCS	M8x12	4
11.....	J-5511729	Large Cover		1
12.....	4200A-5093	Strain Relief	PG13.5	2
13.....	J-5052431	Motor Mounting Plate		1
15.....	TS-2360121	Flat Washer	M12	4
16.....	TS-1540081	Hex Nut	M12	4
17.....	5511745	Adjustable Mount		4
19.....	4200A-B320	Cover		1
20.....	4200A-B321	Pan Head Bolt w/Flange		3
21.....	TS-1540041	Hex Nut	M6	3
27.....	JETLOGO-1	JET Logo	2-3/4"x8"	1
28.....	TS-1533052	Pan Head Screw	M5x16	3
29.....	4200A-B330	Cord Clamp		1
30.....	TS-1540031	Hex Nut	M5	1
33.....	4200A-B334	Label, Voltage		1
34.....	J-5514651	Motor	1-1/2HP 230/460V 3Ph	1
35.....	5512937	Key	5x5x35 mm	1
36.....	4200A-436	Motor Pulley		1
37.....	TS-1523011	Set Screw	M6x6	1
	9145531	Machine Safety Label (not shown)		1