


## Screw Jack Breakdown



### Parts List for SJ-5T/10T/15T/20T/25T Screw Jacks

Index No.	Part No.	Description	Size	Qty.
1	SJ5T-1	Support (SJ-5T, SJ-10T, SJ-15T)		1
	SJ20T-1	Support (SJ-20T, SJ-25T)		1
2	SB-3/4	Steel Ball (SJ-5T, SJ-10T, SJ-15T)	3/4"	1
	SJ20T-02	Steel Ball (SJ-20T, SJ-25T)	29/32"	1
3	SJ5T-03	Shim (SJ-5T, SJ-10T, SJ-15T)		1
	SJ20T-03	Shim (SJ-20T, SJ-25T)		1
4	SJ5T-04	Main Screw		1
	SJ10T-04	Main Screw		1
	SJ15T-04	Main Screw		1
	SJ20T-04	Main Screw		1
	SJ25T-04	Main Screw		1
5	SJ5T-05	Body		1
	SJ10T-05	Body		1
	SJ15T-05	Body		1
	SJ20T-05	Body		1
	SJ25T-05	Body		1
6	SJ5T-ID	I.D. Label		1
	SJ10T-ID	I.D. Label		1
	SJ15T-ID	I.D. Label		1
	SJ20T-ID	I.D. Label		1
	SJ25T-ID	I.D. Label		1
7	SJ5T-WL	Warning Label		1
	SJ10T-WL	Warning Label		1
	SJ15T-WL	Warning Label		1
	SJ20T-WL	Warning Label		1
	SJ25T-WL	Warning Label		1
<b>Optional Accessory</b>				
	440301	Steel Turning Bar (fits SJ-5T)	1/2" x 18"	1
	440302	Steel Turning Bar (fits SJ-10T)	5/8" x 24"	1
	440303	Steel Turning Bar (fits SJ-15T)	3/4" x 36"	1
	440304	Steel Turning Bar (fits SJ-20T/25T)	1" x 42"	1