


Screw Jack Breakdown



Parts List for SJ-5T/10T/15T/20T/25T Screw Jacks

| Index No. | Part No. | Description | Size | Qty. |
|---------------------------|----------|-------------------------------------|------------|------|
| 1 | SJ5T-1 | Support (SJ-5T, SJ-10T, SJ-15T) | | 1 |
| | SJ20T-1 | Support (SJ-20T, SJ-25T) | | 1 |
| 2 | SB-3/4 | Steel Ball (SJ-5T, SJ-10T, SJ-15T) | 3/4" | 1 |
| | SJ20T-02 | Steel Ball (SJ-20T, SJ-25T) | 29/32" | 1 |
| 3 | SJ5T-03 | Shim (SJ-5T, SJ-10T, SJ-15T) | | 1 |
| | SJ20T-03 | Shim (SJ-20T, SJ-25T) | | 1 |
| 4 | SJ5T-04 | Main Screw | | 1 |
| | SJ10T-04 | Main Screw | | 1 |
| | SJ15T-04 | Main Screw | | 1 |
| | SJ20T-04 | Main Screw | | 1 |
| | SJ25T-04 | Main Screw | | 1 |
| 5 | SJ5T-05 | Body | | 1 |
| | SJ10T-05 | Body | | 1 |
| | SJ15T-05 | Body | | 1 |
| | SJ20T-05 | Body | | 1 |
| | SJ25T-05 | Body | | 1 |
| 6 | SJ5T-ID | I.D. Label | | 1 |
| | SJ10T-ID | I.D. Label | | 1 |
| | SJ15T-ID | I.D. Label | | 1 |
| | SJ20T-ID | I.D. Label | | 1 |
| | SJ25T-ID | I.D. Label | | 1 |
| 7 | SJ5T-WL | Warning Label | | 1 |
| | SJ10T-WL | Warning Label | | 1 |
| | SJ15T-WL | Warning Label | | 1 |
| | SJ20T-WL | Warning Label | | 1 |
| | SJ25T-WL | Warning Label | | 1 |
| Optional Accessory | | | | |
| | 440301 | Steel Turning Bar (fits SJ-5T) | 1/2" x 18" | 1 |
| | 440302 | Steel Turning Bar (fits SJ-10T) | 5/8" x 24" | 1 |
| | 440303 | Steel Turning Bar (fits SJ-15T) | 3/4" x 36" | 1 |
| | 440304 | Steel Turning Bar (fits SJ-20T/25T) | 1" x 42" | 1 |