


Main Body Assembly




Main Body Assembly

Index	Part		Size	Qty.
No.	No.	Description		
1.....	JSJ3S-01	Retainer Ring*		2
2.....	JSJ3S-02	Washer.....		2
3.....	JSJ3S-03	Front Wheel*		2
4.....	JSJ3S-04	Side Plate Assembly.....		1
5.....	JSJ3S-05	Lock Washer		2
6.....	JSJ3S-06	Nut	M16.....	2
7.....	JSJ3S-07	Caster Assembly* (incls: #7-10)		2
8.....		Ball Ring.....		2
9.....		Ball Bearing.....		38
10.....		Ball Cover		2
11.....	JSJ3S-11	Lock Washer		4
12.....	JSJ3S-12	Socket Head Cap Screw.....	M12x25	2
13.....	JSJ3S-13	Arm Shaft.....		1
14.....	JSJ3S-14	Retainer Ring		2
15.....	JSJ3S-15	Nut	M10.....	3
16.....	JSJ3S-16	Lock Washer		3
17.....	JSJ3S-17	Shaft		1
18.....	JSJ3S-18	Nut	M12	2
19.....	JSJ3S-19	Bolt.....		2
20.....	JSJ3S-20	Lock Washer		2
21.....	JSJ3S-21	Pin.....		1
22.....	JSJ3S-22	Washer.....		1
23.....	JSJ3S-23	Gear		1
24.....	JSJ3S-24	Pump Pin		1
25.....	JSJ3S-25	Bolt.....		1
26.....	JSJ3S-26	Torsion Spring*		1
27.....	JSJ3S-27	Handle Socket.....		1
28.....	JSJ3S-28	Washer.....		1
29.....	JSJ3S-29	Gear Shaft.....		1
30.....	JSJ3X-30	Power Unit Assembly.....		1
31.....	JSJ3S-31	Bolt*	M6x35	1
32.....	JSJ3S-32	Lower Handle*		1
33.....	JSJ3S-33	Handle Grip*		1
34.....	JSJ3S-34	Upper Handle*		1
35.....	JSJ3S-35	Bolt		2
36.....	JSJ3S-36	Lifting Arm Assembly.....		1
37.....	JSJ3S-37	Saddle*		1
38.....	JSJ3S-38	Retainer Ring		2
39.....	JSJ3S-39	Grease Fitting.....		1
40.....	JSJ3S-40	Cross Head		1
41.....	JSJ3S-41	Pin		1
42.....	JSJ3S-42	Return Spring*		1

* Indicates normal stocked part. Other parts may be purchased on a special order basis only.
Contact JET Equipment & Tools (1-800-274-6848) for details.

Power Unit Assembly



Power Unit Assembly

Index	Part		Description	Size	Qty.
No.	No.				
2.....JSJ3X-P02.....	O-Ring **		30x3.55		1
3.....JSJ3X-P03.....	Tank Nut				1
4.....JSJ3X-P04.....	O-Ring **				2
5.....JSJ3X-P05.....	Cylinder				1
6.....JSJ3X-P06.....	Oil Tank				1
7.....JSJ3X-P07.....	Oil Fill Plug **				1
8.....JSJ3X-P08.....	U-Cup **				1
9.....JSJ3X-P09.....	O-Ring **		33x3.55		1
11.....JSJ3X-P11.....	Gear Retaining Nut.....	M8			1
12.....JSJ3X-P12.....	O-Ring **		16x2.4		1
13.....JSJ3X-P13.....	Release Valve Assembly *				1
14.....JSJ3X-P14.....	Valve Stem				1
15.....JSJ3X-P15.....	Guide Plate				1
16.....JSJ3X-P16.....	Ball	6			1
17.....JSJ3X-P17.....	Seal Washer **				1
18.....JSJ3X-P18.....	Screw				1
19.....JSJ3X-P19.....	Adjustment Screw.....				1
20.....JSJ3X-P20.....	Seal Washer **				1
21.....JSJ3X-P21.....	Wiper **				1
22.....JSJ3X-P22.....	Back Up Ring **				1
23.....JSJ3X-P23.....	O-ring **	16x2.4			1
24.....JSJ3X-P24.....	Base				1
25.....JSJ3X-P25.....	Piston Pump				1
26.....JSJ3X-P26.....	Ball	4			1
27.....JSJ3X-P27.....	Ball	6			1
28.....JSJ3X-P28.....	Screw				1
29.....JSJ3X-P29.....	Ball	4			1
30.....JSJ3X-P30.....	Adapter				1
31.....JSJ3X-P31.....	Spring				1
32.....JSJ3X-P32.....	Ram				1
33.....JSJ3X-P33.....	O-ring **	14x2.4			1
34.....JSJ3X-P34.....	Washer				1
35.....JSJ3X-P35.....	Back Up Ring				1
36.....JSJ3X-P36.....	Spring				1
37.....JSJ3X-P37.....	Ram				1
38.....JSJ3X-P38.....	Back Up Ring **				1
39.....JSJ3X-P39.....	O-ring **	50x2.4			1
40.....JSJ3X-P40.....	Cylinder Gasket **				1
41.....JSJ3X-P41.....	Spring				1
42.....JSJ3X-P42.....	O-ring **	6x3			3
43.....JSJ3X-P43.....	Ball	6			1
44.....JSJ3X-P44.....	Spring				1
45.....JSJ3X-P45.....	Back Up Ring **				2
46.....JSJ3X-P46.....	Screw				1
47.....JSJ3X-P47.....	Ball	6			1
48.....JSJ3X-P48.....	Screw				1
49.....JSJ3X-P49.....	Ball	3			1
50.....JSJ3X-P50.....	Pin				1
.....JSJ3S-SK	Seal Kit * (incls parts marked with an "***")				
.....JSJ3X-30	Power Unit Assembly (incls: index numbers 2-50)				

* Indicates normal stocked part. Other parts may be purchased on a special order basis only.
 Contact JET Equipment & Tools (1-800-274-6848) for details.