

No. 49-16-2793
Blower Attachment
Serial No. N94A

 NOTE: Apply 2g of type "J" grease (49-08-4220) to the bottom side cavity of the Blower Tube (#6).

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
6	-----	Blower Tube (with sleeve and shaft)	(1)
11	05-74-0419	M4 x 113mm Pan Hd. Torx CH Screw	(7)
12	45-03-0014	Blower Screen	(1)
13	43-72-0052	Cone	(1)
14	-----	Blower Screen Housing	(1)
15	-----	Blower Foam	(1)
16	-----	Tube Clamp	(1)
17	05-81-5262	M4 x 18mm ST T-15 B Screw	(7)
18	-----	M4 x 18mm ST Torx T-20 B Screw	(1)
21	31-44-0437	Stage 2 Housing	(1)
22	31-44-0438	Stage 3 Housing	(1)
24	31-12-0116	Long Tip Nozzle	(1)
25	22-08-0013	Blower Input Fan	(3)
26	45-88-0186	Flat Washer 10.5 x 20 x 3mm	(2)
27	20-20-0010	Fan Shaft	(1)
28	40-50-0219	Spring	(1)
34	31-12-0122	Flared Nozzle Attachment Assembly	(1)
35	31-12-0121	Tapered Nozzle Attachment Assembly	(1)
36	14-46-0714	Tube Kit - Gen II Quik-Lok Blower	(1)
37	-----	M5 x 13mm Pan Hd. Torx T-25 B Screw	(2)
39	10-22-0269	Warning Label A (Not Shown)	(1)
40	10-22-0270	Warning Label B (Not Shown)	(1)
41	10-22-0271	Warning Label C (Not Shown)	(1)
42	10-22-0273	Warning Label D (Not Shown)	(1)
43	12-20-0383	Service Nameplate (Not Shown)	(1)
45	14-46-0716	Screen Housing Kit	(1)
46	14-46-0717	Stage 1 Housing Assembly	(1)
47	14-46-0718	Stage 4 Housing Assembly	(1)

SCREW TORQUE SPECIFICATIONS				
FIG.	PART NO.	WHERE USED	SEAT TORQUE	
			(kgf-cm)	(lb-in)
11	05-74-0419	Housing	10-12	9-10
17	05-74-0228	Stage 2 Housing	10-12	9-10
37	-----	Tube Clamp	20-24	17-21

