



SERVICE PARTS LIST

BULLETIN NO.
54-22-1210

SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS		REVISED BULLETIN	DATE
6" DIAMETER BENCH GRINDER			Sept. 2000
CATALOG NO. 4935	STARTING SERIAL NUMBER W10-86	WIRING INSTRUCTION 58-01-0026	

EXAMPLE:



Component Parts (Small #)
Are Included When Ordering
The Assembly (Large #).




FIG.	PART NO.	DESCRIPTION OF PART	QTY	FIG.	PART NO.	DESCRIPTION OF PART	QTY
1	42-38-0250	Rubber Foot	(4)	26	23-40-0600	Rotor, 1/3 H.P. (Incl. Fig. 28)	(1)
2	44-66-5670	Base Plate	(1)	27	06-95-0110	Pan Head Screw Taptite 6-32 x 5/16"	(2)
3	42-20-0630	Base	(1)	28	23-66-1570	Rotary Switch	(1)
4	23-66-1560	Toggle Switch	(1)	29	23-66-1600	Stationary Switch	(1)
5	22-64-1120	Cord Set	(1)	30	45-12-0370	Right Spark Shield	(1)
6	06-10-0400	Carriage Bolt 1/4"-20 x 1/2"	(2)	31	06-55-3150	Right Hand Hex Nut 1/2"-20	(1)
7	06-75-0296	Cap Screw 5/16"-18 x 1/2"	(2)	32	06-75-0075	Cap Screw 1/4"-20 x 5/12"	(4)
8	44-85-0180	Left Tool Rest	(1)	33	42-36-1610	Eyeshield Bracket	(2)
9	42-09-0010	Tool Rest Arm	(1)	34	49-62-0120	P & S Eyeshields	(2)
10	45-88-5220	Washer 1/4" Flat	(6)	35	06-10-0200	Carriage Bolt 10-24 x 5/8"	(2)
11	06-59-1500	Wing Nut 5/16"-18	(2)	36	-----	Grinding Wheel 6" x 3/4" x 1/2"	(1)
12	06-59-2000	Wing Nut 1/4"-20	(4)	37	-----	Grinding Wheel 6" x 3/4" x 1/2"	(1)
13	44-85-0190	Right Tool Rest	(1)			(see catalog)	(1)
14	06-95-5225	Self Tapping Screw 8-32 x 5/16"	(6)	---	12-99-0470	Nameplate	(1)
15	42-92-0680	Guard Cover	(2)			Items Not Shown	
16	06-55-3175	Left Hand Hex Nut 1/2"-20	(1)	---	22-90-0180	Grommet	(1)
17	43-34-0610	Wheel Flange	(4)	---	06-08-0050	Thru Bolt 10-24 x 6-3/4"	(2)
18	06-10-0650	Carriage Bolt 1/2"-20 x 1"	(2)	---	06-55-1050	Hex Nut 10-24	(4)
19	43-54-0590	Guard	(2)				
20	45-12-0360	Left Spark Shield	(1)				
21	42-70-5060	Eyeshield Clip	(2)				
22	42-25-2540	Endbell	(2)				
23	45-88-8095	Bearing Felt Washer	(2)				
24	02-04-1745	Bearing	(2)				
25	23-58-0700	Stator, 1/3 H.P.	(1)				