



MODEL 50-762  
THREE PHASE  
POWER CIRCUIT



MODEL 50-763  
SINGLE PHASE  
POWER CIRCUIT



## Parts List for 50-763 Type 1

Item Number	Part Number	Description	Qty Required
1	488974-00	PAN HEAD SCREW	2
2	492056-00	WASHER	2
3	A04468	SWITCH	1
4	SSF-616-ZN	SCREW .313-24X1.00 H	4
5	1350308S	FLAT WASHER	8
6	A04473	BASE	1
7	1346677	MOTOR ASSY (3HP-1PH)	1
8	1350430S	NUT	4
9	491956-00	WASHER	8
10	902010101206	HEX NUT	4
11	1346555	GASKET	1
12	1343390	SPRING WASHER	12
13	901010600607S	SCREW	12
14	A04475	MOTOR BASE	1
15	901010600648S	CAP SCREW	4
16	A04461	GASKET	1
17	910981	IMPELLER	1
18	1346546	SPECIAL WASHER	1
19	1346545	SPECIAL SCREW	1
20	A04457	HANGER	2
21	A04451	DUST BAG	2
22	A04462	BLOWER SUPPORT	2
23	A15941	BLOWER HOUSING	1
23	1350307S	SCREW	4
24	1350409S	HEX NUT	2
25	901010600635S	SCREW	2
26	A04464	RUBBER PAD	2

## Parts List for 50-763 Type 1

Item Number	Part Number	Description	Qty Required
27	901010600607S	SCREW	6
28	1340637	WASHER	6
29	A15928	BRACKET	2
29	A04458	BASE	2
30	A04465	INTAKE COVER	1
31	488974-00	PAN HEAD SCREW	12
32	902224	INTAKE HOUSING	1
33	488974-00	PAN HEAD SCREW	4
34	1346521	CAP	4
35	A04456	UPPER SUPPORT	2
36	A04470	KNOB	4
37	1243502	WASHER	4
38	A04454	SUPPORT & BASE	1
39	A14366	BAND CLAMP	2
39	A04455	CLAMP	2
40	A04450	PLASTIC DUST BAG	2
41	1344330	FLAT WASHER	16
42	901010600607S	SCREW	16
43	1346532	CASTER	4
44	A04453	HDWE PACK	1
45	A04467	RUN CAPACITOR	1
45	A05125	START CAPACITOR	1
46	A04489	WARNING LABEL	1
47	902713	LABEL	1