



Parts List for 50-820 Type 1

Item Number	Part Number	Description	Qty Required
1	489047-00	CAP SCREW	1
2	904010101604S	STEEL WASHER	1
3	000000-00	No Longer Available	1
4	904010101604S	STEEL WASHER	1
5	902010101300S	HEX NUT	1
6	1346844	UPPER SUPPORT	1
7	1346845	CLAMP	2
8	1346846	LOWER SUPPORT	1
9	1346847	HANDLE COVER	1
10	1346848	FRONT SUPPORT	1
11	1346849	FOOT	6
12	1343545	WASHER	6
13	488974-00	PAN HEAD SCREW	6
15	488979-00	WIRE NUT	1
15	1348467	GROMMET	1
15	1346850	MOTOR ASSY	1
15	1348463	SWITCH HOUSING	1
15	1346563	CAPACITOR (30UF)	1
15	1348465	CLAMP	1
15	901061217383	SCREW	3
15	489563-00	SCREW	1
15	489105-00	SWITCH	1
15	1343758	KEY	1
15	1348466	POWER CORD	1
16	1346851	GASKET	1
17	1346852	BLOWER HOUSING (RH)	1
18	1348231	ROTATION LABEL	1

Parts List for 50-820 Type 1

Item Number	Part Number	Description	Qty Required
19	1346837	WARNING LABEL	1
20	489026-00	HEX NUT	2
21	099389-06	WASHER	2
23	904010312937	WASHER	4
24	901010600607S	SCREW	4
25	000000-00	No Longer Available	1
26	904010101636S	WASHER	1
27	902010201227S	HEX JAM NUT	1
28	901010603118	CAP SCREW	1
29	1346854	CLAMP	1
30	489026-00	HEX NUT	1
31	099389-06	WASHER	1
32	901010600612S	CAP SCREW	1
33	1343390	SPRING WASHER	2
34	1346855	ACORN NUT	2
35	1342476	CLAMP	2
36	000000-00	No Longer Available	1
38	1346856	DUST GATE ASSY	1
39	488974-00	PAN HEAD SCREW	4
40	1246045	MACH SCREW	4
41	000000-00	No Longer Available	1
42	1346836	WARNING LABEL	1
43	1346858	GASKET	1
44	901010600612S	CAP SCREW	2
45	099389-06	WASHER	2
46	1346859	BLOWER HOUSING (LH)	1
47	000000-00	No Longer Available	1

Parts List for 50-820 Type 1

Item Number	Part Number	Description	Qty Required
48	000000-00	No Longer Available	1
49	1343390	SPRING WASHER	1
50	902010101300S	HEX NUT	1
56	1346858	GASKET	1
57	1346856	DUST GATE ASSY	1
58	488974-00	PAN HEAD SCREW	4
59	1246045	MACH SCREW	4
60	1346861	EXHAUST PORT	1
61	902713	LABEL	1
62	000000-00	No Longer Available	1
63	1343390	SPRING WASHER	2
64	1346855	ACORN NUT	2
65	1346862	REAR SUPPORT	1