


REPAIR PARTS

22" ROTARY LAWN MOWER -- MODEL NO. 56dh, PRODUCT NO. 954 05 07-01



REPAIR PARTS

22" ROTARY LAWN MOWER - - MODEL NO. 56dh, PRODUCT NO. 954 05 07-01

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532 08 54-36	Hex Head Washer Screw 1/4-20 x 1-1/2	40	532 12 51-62	Axle Arm Assembly (Rear)
2	532 80 05-47	Trim Plate	41	532 12 50-66	Selector Spring
3	532 85 07-58	Control Bar	42	532 07 78-65	Selector Knob
4	532 85 07-24	Handle Grip	43	532 05 71-43	Washer
5	532 03 69-53	Self-tapping Screw #10-24 x 5/8	44	532 06 16-51	Washer
6	532 06 36-01	Locknut 1/4-20	45	532 08 49-21	Shoulder Bolt 3/8-16
7	532 05 87-14	Handle Bolt 5/16-18 x 1-3/4	46	532 08 80-17	Wheel & Tire Assembly 14.0 x 2.0
8	532 12 51-73	Lower Handle	47	532 08 39-23	Locknut
9	532 06 64-26	Wire Tie	48	532 85 08-45	Hubcap
10	532 08 56-92	Machine Screw 1/4-20 x 2-1/8	49	532 80 03-33	Wheel & Tire Assembly 8.0 x 2.0
11	532 85 14-64	Throttle Control	50	532 06 23-35	Washer
12	532 08 57-23	Washer	51	532 12 50-61	Axle Arm Assembly (Front)
13	532 85 16-70	Engine Zone Control Cable	52	532 05 34-90	Locknut
14	532 75 00-97	Hex Washer Head Screw #10-24 x 1/2	53	532 85 10-84	Hex Head Screw 3/8-24 x 1-3/8 Gr. 8
15	532 12 51-62	Up-Stop Bracket	54	532 85 02-63	Helical Washer 3/8
16	532 12 51-71	Upper Handle	55	532 85 10-74	Hardened Washer
17	532 05 17-93	Hairpin Cotter	56	532 85 09-73	22" Blade
18	532 80 03-57	Rope Guide	57	532 85 15-14	Blade Adapter
19	532 06 36-88	Handle Knob	58	532 12 50-56	Front Baffle
20	532 05 45-83	Self-tapping Screw 1/4-20 x 1/2	59	532 07 44-00	Locknut 3/8-16
21	532 75 01-57	Support Rod	61	532 03 37-50	E-Ring
22	532 75 10-84	Rear Skirt	62	532 08 75-90	Hinge Rod
23	532 08 12-76	Hex Head Washer Screw #10-24 x 1/2	63	532 08 75-89	Torsion Spring
24	532 12 52-07	Skirt Bracket	64	532 08 75-93	Housing Bracket Assembly
25	532 12 50-47	Handle Bracket Assembly (Right)	65	532 85 07-78	Discharge Guard
26	532 12 50-49	Handle Bracket Assembly (Left)	66	532 10 32-51	* Muffler Deflector
27	532 10 73-39	Danger Decal	67	532 09 37-05	* Screw #8-32 x 3/8
28	532 05 92-89	Washer	68	532 21 31-46	* Cable Clamp
29	532 05 51-87	Thread Cutting Screw 5/16-18 x 1-3/4	69	532 10 74-88	Thread Rolling Screw #10-32 x 5/8
30	532 06 23-36	Locknut 3/8-16	70	-----	* Engine - Briggs & Stratton Model No. 124702 Type No. 3118-01
31	532 85 09-98	Thread Rolling Screw 3/8-16 x 1	--	532 12 50-55	Rear Baffle (Not Shown)
32	532 80 14-93	Lawn Mower Housing (Includes Key No. 27)	--	532 80 16-76	Operator's Manual (English)
33	532 80 03-68	Wheel Adjusting Bracket (LF/RR)	--	532 12 84-36	Operator's Manual (French)
34	532 12 50-52	Wheel Support Bracket (Right)	--	532 80 05-69	Decal (Engine)
35	532 12 50-53	Wheel Support Bracket (Left)	--	532 80 05-72	Decal (Housing)
36	532 05 59-12	Hex Head Bolt 3/8-16 x 3/4	--	532 85 07-88	Decal (Trim Plate)
37	532 80 03-70	Wheel Adjusting Bracket (RF/LR)			
38	532 08 49-20	Spacer			
39	532 08 83-48	Washer			

* These parts must be purchased through an authorized Briggs & Stratton dealer.