



SERVICE PARTS LIST

BULLETIN NO.
55-40-0272

SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS		REVISED BULLETIN 55-40-0271	DATE Dec. '88
4-3/4" DEEP CUT BANDSAW			
CATALOG NO. 6232-4	STARTING SERIAL NO. 678-1625	WIRING INSTRUCTION 58-03-0729	

EXAMPLE:

00 0

Component Parts (Small #) Are Included
When Ordering The Assembly (Large #).

FIG.	PART NO.	DESCRIPTION OF PART	NO.	REQ.	FIG.	PART NO.	DESCRIPTION OF PART	NO.	REQ.
1	22-64-4480	Cord Set	(1)		60	42-12-0070	Blade Pulley Axle	(2)	
2	44-76-0120	Cord Protector	(1)		★ 61	06-82-8864	10-24 x 1/2" Pan Hd. Torx Sem	(2)	
3	31-17-0155	Cord Clamp	(1)		62	42-38-0040	Bumper	(1)	
★ 4	06-82-7270	8-16x5/8" Slit. Plastite Torx Screw	(2)		★ 63	06-82-5330	10-32 x 5/8" Pan Hd. Tapt. Torx	(2)	
★ 5	06-82-5292	1/4-20x7/8" Pan Hd. Taptite Torx Screw	(6)		64	42-28-0205	Front Blade Guide Block	(1)	
6	31-44-0490	Right Handle Half	(1)		65	42-28-0210	Rear Blade Guide Block	(1)	
★ 7	06-82-7270	8-16x7/8" Slit. Plastite Torx Screw	(4)		66	02-25-0260	Cam Follower	(6)	
8	31-44-0495	Left Handle Half	(1)		★ 67	06-82-5574	10-24 x 7/8" Pan Hd. Tapt. Torx	(2)	
★ 9	06-82-7409	8-16x1/2" Pan Hd. Plastite Torx Screw	(1)		★ 68	06-82-8864	10-24 x 1/2" Pan Hd. Torx Sem.	(1)	
10	23-66-0766	Variable Speed Control Switch	(1)		69	43-54-0250	Blade Guard	(1)	
★ 11	06-82-7252	8-32x3/8" Pan Hd. Slit. Tapt. Torx	(1)		★ 70	06-82-9264	10-24 x 1/2" Pan Hd. Tapt. Torx Shld.	(1)	
12	28-62-0031	Blade Release Lever	(1)		71	48-39-0510	Bandsaw Blade	(1)	
13	06-42-2200	Woodruff Key	(1)		72	02-50-3230	Needle Bearing	(1)	
14	45-88-7105	Wave Washer	(1)		73	14-73-0160	Blade Release Shaft Assembly	(1)	
★ 15	06-82-3024	1/4-20 x 1/2" Fil. Hd. Taptite Torx Screw	(3)		74	45-36-0720	Retaining Plate Spacer	(4)	
16	06-75-4675	3/8-16 x 1" Skt. Hd. Screw	(1)		75	44-52-0120	Blade Backing Pad	(1)	
17	31-44-0330	Front Handle	(1)		★ 76	28-41-0920	Front Pulley Guard	(1)	
18	23-44-0220	Brush Cap	(2)		77	02-50-1630	Needle Bearing	(1)	
19	22-18-0715	Carbon Brush Assembly	(2)		78	44-66-0550	Pulley Guard Retaining Plate	(2)	
20	22-22-1355	Brush Holder Assembly	(2)		★ 79	06-82-3810	1/4-20 x 1-1/4" Flat Hd. Taptite Torx	(4)	
★ 21	06-82-5298	1/4-20 x 1" Pan Hd. Taptite Torx Screw	(4)		80	40-50-0710	Blade Tension Spring	(2)	
22	28-90-0200	Pulley Support	(1)		81	06-75-0255	1/4-20 x 4" Hex Hd. Screw	(2)	
★ 23	28-50-6380	Motor Housing	(1)		82	06-57-5000	1/4-20 Lock Nut	(2)	
24	02-04-0911	Ball Bearing	(1)		83	42-18-0190	Blade Tension Bar	(2)	
25	31-55-0145	Coil Shield	(1)		★ 84	06-82-5298	1/4-20 x 1" Pan Hd. Taptite Torx Screw	(2)	
26	23-16-0425	Field Insulator	(1)		85	22-84-0770	Fan	(1)	
27	18-54-0100	220 Volt Field	(1)						
★ 28	06-82-7410	8-16x1-7/8" Pan Hd. Plastite Torx Screw	(2)						
29	31-05-0170	Fan Baffle	(1)						
30	16-54-0100	220 Volt Armature	(1)						
31	02-04-1040	Ball Bearing	(1)						
★ 32	06-65-1155	3/16 x 5/8" Groove Pin	(1)						
★ 33	28-28-1699	Diaphragm	(1)						
34	02-04-1020	Ball Bearing	(1)						
35	32-40-1680	Intermediate Gear	(1)						
36	06-42-1200	Woodruff Key	(1)						
37	36-18-0050	Worm Shaft	(1)						
38	02-04-1030	Ball Bearing	(1)						
★ 39	28-14-2110	Gear Case	(1)						
★ 40	06-82-5716	1/4-20 x 1-1/4" Pan Hd. Taptite Torx	(4)						
41	06-85-0200	Nameplate Screw	(2)						
42	12-99-0065	Nameplate Blank	(1)						
★ 43	06-82-5394	5/16-18x13/16" Pan Hd. Torx	(2)						
44	02-04-1210	Ball Bearing	(1)						
45	32-90-0110	Worm Gear	(1)						
46	06-42-2200	Woodruff Key	(1)						
47	36-66-0525	Worm Gear Shaft	(1)						
48	02-04-2700	Ball Bearing	(1)						
★ 49	06-82-8842	8-32 x 3/8" Pan Hd. Taptite Torx Sem	(2)						
51	42-60-0190	Roller Chain	(1)						
52	45-69-0010	Blade Pulley Tire	(2)						
53	45-88-7165	Pulley Hub Washer	(4)						
54	34-60-1400	Snap Ring	(2)						
55	28-20-1221	Blade Pulley Cover	(2)						
★ 56	06-82-3060	1/4-20 x 1-5/16" Fil. Hd. Tapt. Torx	(3)						
57	28-95-0120	Blade Pulley	(2)						
58	42-40-0580	Sleeve Bearing	(4)						
59	31-88-0050	Sprocket	(1)						

FIG. NOTES

- 34,35,
 - 36,37,38 Assemble and install in Gear Case before 44 thru 48.
 - 43 Apply Type 242 Blue Loctite. Torque to 75-115 in./lbs.
 - 11,61, Apply Type 242 Blue Loctite.
 - 63,67
 - 66 Torque to 20-25 in./lbs.
 - 83 Dimension between outside edges of blade tension bars 3-11/16" ± 1/16"
- FIG. LUBRICATION**
- 39 3 oz. Type "G" Grease, No. 49-08-4140.
 - 1.5 oz. in each of two locations. (See Illustration).

