



## Parts List for 22 Ton Bottle Jack

Index No.	Part No.	Description	Size	Qty
1	JBJ22-1	Body		1
2	JBJ12-2	Safety Valve Screw		1
3	JBJ12-3	O-Ring*	7.1 X 2.65 mm	2
4	JBJ12-4	Safety Valve Spring		1
5	JBJ12-5	Ball Seat		1
6	SB-4MM	Steel Ball	4 mm	1
7	JBJ12-7	Release Rod		1
8	SB-6MM	Steel Ball	6 mm	1
9	JBJ12-9	Oil Fill Plug*		1
10	SB-5MM	Steel Ball	5 mm	2
11	JBJ22-2	Washer		1
15	JBJ22-6	O-Ring*	45 x 5.3 mm	1
16	JBJ22-7	Sealing Washer*		1
18	JBJ22-9	Ram		1
19	JBJ22-10	Bushing		2
20	JBJ22-11	O-Ring*	51.5 x 4.6 mm	1
21	JBJ22-12	Snap Ring		1
22	JBJ22-13	Snap Ring		1
23	JBJ22-14	Supporting Plate		1
30	JBJ12-26	O-Ring*	6.6 x 3 mm	1
31	JBJ12-27	Nylon Gasket*		1
32	JBJ12-28	Dustproof Ring*		1
33	JBJ22-15	Pump Plunger		1
34	JBJ22-16	Pin		1
35	JBJ12-31	Pin		3
36	JBJ22-17	Rod Joint		1
37	JBJ22-18	Pin		1
38	JBJ22-19	Handle Socket		1
39	JBJ22-20	Rear Handle		1
40	JBJ22-21	Middle Handle		1
41	JBJ22-22	Front Handle		1
42	SB-6MM	Steel Ball	6 mm	2
43	JBJ5-3	Spring		2
44	JBJ5-4	Copper Washer*		2
45	JBJ5-5	Screw	M6 x 10	2
	JBJ22-RK	Repair Kit (not shown)		

Items marked with an asterisk (\*) are included in the Repair Kit

### Ordering Replacement Parts

To order parts or reach our service department, call 800-274-6848 Monday through Friday (see our website for business hours, [www.waltermeier.com](http://www.waltermeier.com)). Having the Model Number and Serial Number of your tool available when you call will allow us to serve you quickly and accurately.