

SERVICE PARTS LIST

SPECIAL SCREWDRIVER

BUL. 54-42-5501

REVISED BUL. 54-42-5500 DATE Sept. '74

Catalog No. **6798-1** Starting Serial No. **450-6758**

WIRING INSTRUCTIONS **58-01-0645**

Specify Catalog and Serial No. when ordering parts

0-2500 R.P.M.

FOR 230V TOOL USE:
 22-64-2665 CORD SET
 22-18-0375 CARBON BRUSH
 18-26-1160 FIELD
 16-26-1295 ARMATURE




FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.	FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
★ 1	22-64-0665	Cord Set	(1)	28	45-88-7280	Nylon Thrust Washer	(1)
2	06-81-0400	8-32x3/4 Pan Head Screw	(4)	29	32-40-1611	Intermediate Gear	(1)
3	06-81-0450	8-32x3/8 Pan Head Screw	(4)	30	06-42-0400	Woodruff Key	(1)
★ 4	31-44-0280	R.H. Handle Half	(1)	31	36-66-4100	Intermediate Pinion Shaft	(1)
★ 5	23-66-0792	Rev. Speed Control Switch	(1)	32	02-50-1635	Needle Bearing	(1)
7	06-81-8625	6-32x1/4 Ground Screw	(1)	33	28-14-1210	Gear Case (Includes 06-65-0825 Groove Pin)	(1)
8	23-44-0020	Brush Retaining Screw	(2)	34	02-08-0210	Ball Bearing	(1)
★ 9	22-18-0155	Carbon Brush	(2)	35	32-10-2500	Clutch Gear	(1)
★ 10	23-86-0105	Washer	(2)	36	45-88-0550	Thrust Washer	(2)
11	22-22-0251	Brush Holder Assy.	(2)	37	02-80-0100	Thrust Bearing	(1)
12	06-83-2430	10-32x1/4 Hdls. Skt. Screw	(2)	38	40-50-6600	Separator Spring	(1)
★ 13	12-99-0021	Nameplate	(1)	39	42-66-0751	Drive Chuck (incl. figs. 40 thru 42)	(1)
14	06-85-0200	6x1/4 Round Hd. Type Z Screw	(2)	40	02-50-1610	Needle Bearing	(1)
★ 15	31-44-0290	L.H. Handle Half	(1)	41	02-55-0150	Loose Roller Bearing	(1)
16	28-50-6091	Motor Housing (Incl. Fig. 17)	(1)	★ 42	40-50-1450	Bit Retaining Spring	(1)
17	45-30-0120	Ball Brg. Retaining Slug	(1)	★ 43	02-50-4050	Needle Bearing	(1)
18	02-04-0740	Ball Bearing	(1)	44	06-81-6740	8-32 x 2 Fil. Hd. Sem	(2)
19	18-22-1160	115 V. Field	(1)	45	06-81-6550	8-32 x 1-1/2 Fil. Hd. Sem	(2)
20	45-36-0601	Baffle Spacer	(2)	46	48-32-2500	Bit Housing	(1)
21	31-05-0010	Baffle	(1)	47	49-26-0250	1/4 Hex Socket Locator	(1)
22	45-88-7170	Washer	(2)		49-26-0312	5/16 Hex Socket Locator	(1)
23	16-22-1295	115 V. Armature	(1)		49-26-0375	3/8 Hex Socket Locator	(1)
24	06-81-8695	6-32x2-7/16 Round Hd. Sems	(2)	48	49-26-0600	Washer Head Screw Locator	(1)
25	02-04-0880	Ball Bearing	(1)	49	48-32-2050	1/4 Driver (For Sockets)	(1)
26	28-28-1451	Diaphragm	(1)	50	49-66-3010	5/16 Hex Socket	(1)
27	02-50-1210	Needle Bearing	(1)	★ 51	12-98-7081	Caution Plate (Not Shown)	(1)