



PORTER-CABLE

PLUNGE ROUTER BASE

WARNING: Electrical repairs should only be attempted by trained repairmen. Contact the nearest Porter-Cable Service Center or other competent repair center.

6931





Parts List for 694 Type 1

Item Number	Part Number	Description	Qty Required
1	874299	FAN	1
1	903660	ARMATURE	1
2	904289	SS/A-FIELD	1
3	N031652	BRUSH	2
3	803483	BRUSH CAP	2
3	873497	BRUSH HOLDER	2
4	A22756	SWITCH	1
4	903426	CONTROL-SPEED	1
4	882185	SCREW MACHINE STEEL	1
5	839549	CORD	1
6	152684-00	TERMINAL	1
11	855284	BEARING	1
11	878064SV	BEARING	1
52	903967SV	CASING & PINS FRONT	1
52	A22753	REAR HOUSING	1
52	905490	MOTOR CAP	1
81	875893	COLLET NUT	1
83	872793	CHUCK	1
83	42999	1/4 INCH COLLET ASSY	1
83	42975	3/8 INCH COLLET ASSY	1
83	42975	3/8 INCH COLLET ASSY	1
83	42950	1/2 INCH COLLET ASSY	1
83	876671	COLLET 1/2 INCH	1
83	876669	COLLET 1/4 INCH	1
83	876670	COLLET 3/8 INCH	1
98	823030	SNAP-RING	1
100	896772	BASE & COLUMN ASSY	1

Parts List for 694 Type 1

Item Number	Part Number	Description	Qty Required
101	896774	ADAPTER ASSY	1
102	897187	COLUMN	1
103	897187	COLUMN	1
104	698805	TURRET	1
105	896769	STOP SCREW	1
106	892552	LEVER	1
107	872242	SCREW	1
108	699675	CLAMP SCREW	1
109	892531	SPRING SS/A	1
110	699563	SET SCREW	1
111	699552	CLAMP PLUG	1
112	872729	ROLLED PIN	1
113	875050	KNOB	1
113	800995	BASE KNOB	1
114	802425	WASHER	1
115	699560	SET SCREW	1
116	802752	WASHER	1
117	873309	SCREW	1
118	699399	POINTER	1
119	881290	KNOB	1
121	699991	DEPTH ROD	1
122	892174	NUT	1
123	699553	STOP COLLAR	1
124	850802	WASHER	1
125	A06829	SCALE	1
126	897161	KNOB	1
127	873315	CLAMP	1

Parts List for 694 Type 1

Item Number	Part Number	Description	Qty Required
128	699558	BUSHING	1
129	699400	SPRING GUIDE	1
130	801752	SCREW	1
131	862641	NUT	1
132	883806	SCREW	1
133	685533	WASHER	1
134	850552	SPRING	1
135	895591	WASHER	1
136	860687	BALL	1
139	886538	SCREW	1
140	872762	SHIELD	1
141	875807	SUB BASE	1
141	42186	ROUTER SUB-BASE	1
142	874117	SCREW	1
142	688860	SCREW	1
144	699556	BUSHING-STOP	1
145	699561	SPRING	1
146	872789	SHLDER BEARING	1
147	802430	LOCKWASHER	1
148	885517	NUT	1
150	903595	NUT	1
152	000000-00	No Longer Available	1
223	872998	DEPTH RING	1
225	800995	BASE KNOB	1
226	802425	WASHER	1
229	802306	HEX HEAD SCREW	1
230	42188	ROUTER SUB BASE	1

Parts List for 694 Type 1

Item Number	Part Number	Description	Qty Required
231	688860	SCREW	1
233	5140096-05	SUB BASE	1
234	800869	SPRING	3
239	903118	PIN	1
240	903114	BUCKLE	1
241	903120	SHAFT	1
242	A00323	WEAR PLATE	1
243	802417	WASHER	1
244	903693	NUT	1
245	42160	ROUTER EDGE GUIDE	1
246	803160	SCREW	1
247	882810	KNOB	1
248	824588	ROD GUIDE	1
249	000000-00	No Longer Available	1
249	000000-00	No Longer Available	1
251	A22709	OPEN-END WRENCH	1
300	878389	SCREW	1
302	885267	O RING	1
303	803632	SET-SCREW	1
304	803496	WASHER	1
306	876965	SCREW	1
308	802426	RING	1
310	901266	STRAIN RELIEVER	1
311	800835	PIN	1
313	682063	CONNECTOR VS	1
315	892780	SCREW	1
320	681260	SCREW & WASHER	1

Parts List for 694 Type 1

Item Number	Part Number	Description	Qty Required
321	874137	CORD CLAMP	1
322	878262	SCREW	1
323	887452	DUST SHIELD	1
800	883807	GREASE	1
856	000000-00	No Longer Available	1
856	000000-00	No Longer Available	1
856	802876	ALLEN WRENCH	1
856	905230	HOLDER-WRENCH	1