


## Table and Motor – Assembly




## Table and Motor – Parts

Index No.	Part No.	Description	Size	Qty.
1.....	EHVS80CS-01.....	Base .....		1
2.....	EHVS80-02N.....	Push Button Switch.....		1
3.....	EHVS80-03N.....	Switch Panel .....		1
4.....	TS-081C082.....	Pan Head Screw.....	#10-24x1-1/2"	3
5.....	EHVS80-02B.....	Switch Box .....		1
6.....	TS-0560071.....	Hex Nut.....	#10-24 .....	5
7.....	EHVS80-07.....	Strain Relief .....		2
8.....	EHVS80-08.....	Work Table Bar .....		1
9.....	TS-0640091.....	Nylon Insert Lock Nut.....	3/8"-16 .....	1
10.....	EHVS80-10.....	Locking Block .....		1
11.....	EHVS80-11.....	Spring Pin .....	Ø4 .....	1
12.....	EHVS80-12.....	Lock Handle .....		1
13.....	10102023A.....	Knob .....		1
	EHVS80-12A.....	Lock Handle Assembly (index #12,13).....		1
14.....	S0430525.....	Key .....	5x5x25 .....	1
15.....	TS-0050031.....	Hex Cap Screw .....	1/4"-20x3/4" .....	1
16.....	TS-0680021.....	Flat Washer.....	1/4" .....	5
17.....	EHVS80-17.....	Table .....		1
18.....	EHVS80 -18.....	Screw .....	M10 .....	2
19.....	TS-1540071.....	Hex Nut.....	M10 .....	2
20.....	EHVS80-20.....	Guide Block .....		2
21.....	EHVS80-21.....	Fence .....		1
22.....	EHVS80-22A.....	JET Knob .....	M8x12mm .....	3
23.....	OES80CS-23.....	Drive Drum (serial no. 05110394 and higher) .....		1
24.....	EHVS80-24.....	Guide Bar .....		1
25.....	S0310306.....	Pin .....	Ø3 .....	1
26.....	TS-0267021.....	Set Screw .....	1/4"-20x1/4" .....	1
27.....	EHVS80-27.....	Location Plate .....		1
28.....	EHVS80-28.....	Pointer .....		1
29.....		Sanding Belt (local purchase) .....	6"W x 89"L .....	1
30.....	10104046.....	Miter Gauge Body .....		1
	EHVS80-MG.....	Miter Gauge Assembly (index #20,24-28,30-33,41) .....		1
31.....	TS-081B042.....	Pan Head Screw .....	#8-32x5/8" .....	3
32.....	TS-0560061.....	Hex Nut .....	#8-32 .....	3
33.....	EHVS80-33.....	Knob .....		1
34.....	20101048.....	Platen .....		1
35.....	OES80CS-135.....	Side Plate .....		1
	TS-0051061.....	Hex Cap Screw (motor plate—not shown) .....	5/16"-18x1-1/4" .....	2
	TS-0561021.....	Hex Nut (motor plate—not shown) .....	5/16"-18 .....	2
36.....	EHVS80-36A.....	JET Knob .....	M8x35mm .....	1
37.....	EHVS80-37A.....	Pin .....	Ø6x40mm .....	1
38.....	TS-0561011.....	Hex Nut .....	1/4"-20 .....	2
39.....	EHVS80-39A.....	Spacer .....		1
40.....	TS-0733031.....	External Tooth Lock Washer .....	#10 .....	11
41.....	EHVS80-28A.....	Location Block .....		1
42.....	TS-0561031.....	Hex Nut .....	3/8"-16 .....	1
43.....	TS-0051021.....	Hex Cap Screw .....	5/16"-18x5/8" .....	4
44.....	TS-0720091.....	Lock Washer .....	3/8" .....	2
45.....	EHVS80-49.....	Washer Head Screw .....	#10-24 x 3/8" .....	3
46.....	EHVS80-57.....	Tilt Scale .....		1
47.....	TS-081C052.....	Pan Head Screw .....	#10-24x3/4" .....	1
48.....	EHVS80-59.....	Pointer .....		1
49.....	TS-081C022.....	Pan Head Screw .....	#10-24x3/8" .....	2
50.....	OES80CS-150.....	Motor .....	1-1/2HP, 1Ph .....	1
51.....	TS-0051061.....	Hex Cap Screw .....	5/16"-18x1-1/4" .....	5

## Table and Motor – Parts

<b>Index No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
52.....	TS-0680031 .....	Flat Washer.....	5/16" .....	10
53.....	OES80CS-153 .....	Pin.....		2
54.....	EHVS80-67 .....	Motor Cord.....		1
55.....	OES80CS-155 .....	Dust Port.....		1
56.....	OES80CS-156 .....	Sanding Belt Cover.....		1
57.....	EHVS80-70A .....	Up-Down Table Mount Plate.....		2
58.....	EHVS80-71A .....	JET Knob .....	M8X20mm .....	4
59.....	EHVS80-72 .....	Back Stop Bracket .....		1
60.....	TS-0720081 .....	Lock Washer .....	5/16" .....	14
61.....	TS-0561021 .....	Hex Nut.....	5/16"-18 .....	6
62.....	TS-0051061 .....	Hex Cap Screw .....	5/16"-18x1-1/4" .....	2
63.....	TS-2285121 .....	Flat Head Screw .....	M5x12 .....	8
64.....	TS-2284201 .....	Flat Head Screw .....	M4x20 .....	8
65.....	EHVS80-94 .....	Extension Table .....		1
66.....	EHVS80-96 .....	Supporting Rod .....		1
67.....	EHVS80-57A .....	Tilt Angle Scale Label .....		1
68.....	EHVS80-108 .....	Direction Label .....		1
69.....	EHVS80-107 .....	Warning Label .....		1
70.....	EHVS80-68 .....	Power Cord .....		1
71.....	OES80CS-171 .....	Hinge .....		2
72.....	OES80CS-172 .....	Knob .....	M6 .....	2
73.....	OES80CS-173 .....	Supporting Seat .....		1
74.....	TS-0206041 .....	Socket Head Cap Screw .....	#10-24x3/4" .....	2
75.....	OES80CS-175 .....	Spacer .....		2
76.....	EHVS80-34G .....	Graphite Pad .....		1
77.....	EHVS80-51 .....	Belt Tension Arm .....		1
78.....	EHVS80-54 .....	Tension Arm Handle .....		1
79.....	OES80CS-179 .....	Connection Plate .....		1
80.....	EHVS80-111 .....	Drum Guard .....		1
81.....	OES80CS-181 .....	ID Label .....		1
82.....	OES80CS-182 .....	Hinge Bracket .....		2

## Idle Drum – Assembly




## Idle Drum – Parts

Index No.	Part No.	Description	Size	Qty.
.....	OES80CS-IDRA	Idle Drum Complete Assembly (index # 1-72)		1
1.....	OES80CS-201	Tension Bar		1
2.....	OES80CS-203	Spring		1
3.....	TS-0561021	Hex Nut	5/16"	1
13.....	TS-1523011	Socket Set Screw	M6x6	2
15.....	S0400545	Key	5x5x45mm	1
16.....	OES80CS-216	Worm		1
17.....	OES80CS-217	Spacer		1
18.....	S0400425	Key	4x4x25	1
19.....	TS-0640081	Nylon Insert Lock Nut	5/16"	6
20.....	TS-0680031	Flat Washer	5/16"	4
22.....	TS-0720081	Lock Washer	5/16"	6
23.....	TS-2342141	Nylon Insert Lock Nut	M14	2
24.....	OES80CS-224	Bracket		1
25.....	TS-0050031	Hex Cap Screw	1/4"-20x3/4"	2
26.....	OES80CS-226N	Lead Screw		1
27.....	OES80CS-227	Spring		1
28.....	OES80CS-228	Ball Bearing	.698	3
29.....	OES80CS-229	Retaining Ring	STW-8	1
30.....	TS-1502051	Socket Head Cap Screw	M5x20	2
31.....	TS-0208061	Socket Head Cap Screw	5/16"x1"	1
32.....	TS-2284121	Flat Head Screw	M4x12	3
34.....	BB-6202VV	Ball Bearing	6202LLU	2
35.....	OES80CS-235	Bearing Housing		1
36.....	BB6003ZZ	Ball Bearing	.6003ZZ	1
37.....	S0400430	Key	4x4x30	1
38.....	OES80CS-238	Gear Housing		1
39.....	TS-1502021	Socket Head Cap Screw	M5x10	5
40.....	OES80CS-240	Bushing		2
41.....	OES80CS-241	Cam		1
42.....	OES80CS-242	Worm Gear		1
43.....	OES80CS-243	Worm Gear Shaft		1
44.....	OES80CS-244	Column		2
48.....	TS-0051081	Hex Cap Screw	5/16"-18x1-3/4"	1
49.....	TS-1551031	Lock Washer	M5	6
50.....	OES80CS-250	Rod		1
52.....	EHVS80-81	Belt Tracking Tool		1
53.....	TS-0810012	Round Head Slotted Machine Screw	#10-24x1/4"	4
54.....	OES80CS-254	Self Tapping Screw	M3x6	1
55.....	OES80CS-255	Dust Hood (Left)		1
56.....	OES80CS-256	Dust Hood (Right)		1
57.....	OES80CS-257	Ring		2
58.....	OES80CS-258	Wave Washer		2
59.....	OES80CS-259	Idle Drum		1
60.....	OES80CS-260	Track Adjusting Block		1
61.....	OES80CS-261	Drive Shaft		1
62.....	OES80CS-262	Button Head Socket Screw	5/16"X1-3/4	2
63.....	OES80CS-263	Guard		1
65.....	OES80CS-265	Foam Sheet for Drive Shaft		1
66.....	OES80CS-266	Idle Drum Bracket		1
67.....	OES80CS-267	Track Adjusting Screw		1
68.....	OES80CS-268	Track Adjusting Nut		1
69.....	OES80CS-269	Retaining Ring	S10	1
70.....	OES80CS-270	Bearing Housing		1
71.....	OES80CS-271	Foam Sheet for Lead Screw		1
72.....	OES80CS-272	Cone Disc Spring		2


## Stand Assembly

Index No.	Part No.	Description	Size	Qty.
1.....	TS-0680031 .....	Flat Washer.....	5/16"	22
2.....	TS-0720081 .....	Lock Washer .....	5/16"	10
3.....	TS-0561021 .....	Hex Nut.....	5/16"-18	8
4.....	EHVS80CS-S04 .....	Side Panel .....		2
5.....	EHVS80CS-S05 .....	Pad.....		4
6.....	EHVS80CS-S06 .....	Screw .....		4
7.....	EHVS80CS-S07 .....	Rear Panel.....		1
8.....	TS-0561021 .....	Hex Nut.....	5/16"-18	4
9.....	TS-0051061 .....	Hex Cap Screw .....	5/16"-18x1-1/4"	2
10.....	TS-1533032 .....	Pan Head Screw.....	M5x10	2
11.....	EHVS80CS-S11 .....	Door .....		1
12.....	EHVS80CS-S12 .....	Shelf .....		1
13.....	EHVS80CS-S13 .....	Latch Assembly .....		1
14.....	TS-1551031 .....	Lock Washer .....	M5	2
15.....	EHVS80CS-S15 .....	Front Panel (W/Door).....		1
16.....	EHVS80CS-S16 .....	Screw .....		2
17.....	EHVS80CS-S17 .....	JET Label.....		1
18.....	TS-1550031 .....	Flat Washer.....	M5	2
19.....	TS-0081031 .....	Hex Cap Screw .....	5/16"-18x3/4"	8



# Wiring Diagram

EHVS-80CS ELECTRICAL SCHEMATIC-115V



EHVS-80CS ELECTRICAL SCHEMATIC-230V

