



Parts List for 7144 Type 1

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
2	000000-00	No Longer Available	1
3	140994-00	BRUSH	2
4	000000-00	No Longer Available	1
5	140998-00	HOLDER, BRUSH	2
6	000000-00	No Longer Available	1
7	90678-98	CORD/6FT./18-2	1
8	000000-00	No Longer Available	1
9	000000-00	No Longer Available	1
10	000000-00	No Longer Available	1
11	037381-00	WASHER	2
12	000000-00	No Longer Available	1
13	000000-00	No Longer Available	1
14	000000-00	No Longer Available	1
15	000000-00	No Longer Available	1
16	000000-00	No Longer Available	1
18	234900-02	PLUG 120V 2WIRE	1
19	000000-00	No Longer Available	1
20	000000-00	No Longer Available	1
21	000903-00	BALL	2
22	000000-00	No Longer Available	1
23	000000-00	No Longer Available	8
24	679303-00	CHUCK & KEY	1
25	065288-01	CH KEY HOLDER	1
25	000000-00	No Longer Available	1
25	330034-00	KEY,CHUCK	1
26	000000-00	No Longer Available	1

Parts List for 7144 Type 1

Item Number	Part Number	Description	Qty Required
28	000000-00	No Longer Available	1
29	157312-00	SCREW,SPEC.,LH	1
30	000000-00	No Longer Available	1
31	000000-00	No Longer Available	1
32	000000-00	No Longer Available	1
33	000000-00	No Longer Available	1
34	99368-01	NUT,HEX	1
35	000000-00	No Longer Available	1
36	000000-00	No Longer Available	1
37	000000-00	No Longer Available	1
861	000000-00	No Longer Available	1
861	000000-00	No Longer Available	1