



Parts List for 7157 Type 1

Item Number	Part Number	Description	Qty Required
1	148140-01	ARMATURE & FAN	1
2	142959-71	FIELD	1
3	140994-00	BRUSH	2
4	148142-00	RING,BR.& SPRG.	1
6	148146-00	SWITCH,VS	1
7	448557-98	CORD/10FT./18-2	1
8	158478-00	SINK,HEAT	2
10	157315-00	WASHER,SPRING	2
11	51407-00	WASHER	2
12	283875-00	HOUSING & COVER	1
13	148134-00SV	GEAR & PINION	1
14	148139-00	BEARING,SPHER.	2
17	148481-00	PROTECTOR,CORD	1
19	148338-00	PLATE,THRUST	1
20	148157-01S	SPINDLE-GR&BRG	1
21	000903-00	BALL	1
23	330019-04	SCREW,PLASTITE	8
24	330075-25	KEYLESS CHUCK	1
26	233304-00	NAMEPLATE-SHEET	1
28	147910-00	ACTUATOR,SWITCH	1
29	157312-00	SCREW,SPEC.,LH	1
30	330001-03	BEARING,SLEEVE	1
861	000000-00	No Longer Available	1
861	000000-00	No Longer Available	1