



## Parts List for 74146 Type 1

| Item Number | Part Number | Description         | Qty Required |
|-------------|-------------|---------------------|--------------|
| 1           | 383994-00   | SWITCH,ON/OFF       | 1            |
| 6           | 330013-02   | SCREW,PLASTIC       | 5            |
| 9           | 380087-00   | HANDLE,AUXILLRY     | 1            |
| 10          | 380503-00   | SCREW               | 1            |
| 11          | 090914-00   | WING NUT            | 1            |
| 17          | 33314-00    | CONNECTOR           | 2            |
| 18          | 000000-00   | No Longer Available | 1            |
| 835         | 000000-00   | No Longer Available | 1            |