


PORTER-CABLE POLISHER

WARNING: Electrical repairs should only be attempted by trained repairmen. Contact the nearest Porter-Cable Service Center or other competent repair center

7420



Parts List for 7420 Type 2

Item Number	Part Number	Description	Qty Required
1	876731	CORD	1
2	211125	ARMATURE	1
3	261254	FIELD	1
4	205826	MOTOR HOUSING	1
5	206903	SEAL	1
8	194816	RETAINING CLIP	2
9	206245	SCREW	2
9	195715	SCREW	2
10	254442	BEARING	1
11	254443	BEARING	1
12	211710	BRUSH	2
13	102830	SEAL	1
14	320730	REPAIR KIT	1
15	214892	BEARING	1
16	205990	SCREW	4
17	205834	BRUSH COVER	2
18	205931	BRUSH HOLDER	2
19	103519	STRAIN RELIEVER	1
20	190012	BUFFER SWITCH	1
21	259982	CLAMP	1
21	116815	CORD CLAMP	1
23	320730	REPAIR KIT	1
24	209783	SCREW	4
25	105872	SCREW	4
26	203858	SCREW	4
27	257354	BEARING MOUNT	1
28	258573	SCREW	10

Parts List for 7420 Type 2

Item Number	Part Number	Description	Qty Required
29	256157	SEAL	1
33	213438	CONTROL MODULE	1
33	206784	COVER	1
33	201596	SCREW	4
34	211796	SCREW	10
35	259094	GEAR HOUSING COVER	1
36	176524	SPACER	1
36	176532	SHIM	1
37	176559	SEAL	1
38	259666	GEAR HOUSING	1
39	253460	BEARING RETAINER	1
40	176648	BAFFLE	1
41	196169	SCREW	10
42	176788	GEAR HSG COVER	1
43	213276	SPINDLE SHAFT	1
44	199141	BUSHING	1
45	176826	WASHER	1
46	176834	SEAL	1
47	207144	FAN	1
48	259100	HANDLE SET	1
49	189979	SWITCH LOCK	1
50	190004	LOCK SPRING	1
51	189987	PUSH BUTTON	1
52	189995	FELT RING	1
53	195693	SCREW	4
57	253433	AUX HANDLE	1
60	250329	LOCK BUTTON	1

Parts List for 7420 Type 2

Item Number	Part Number	Description	Qty Required
61	250589	SPRING	1
62	250266	SEAL	1
63	250694	TOOL REST	1
64	110140	SCREW	10
65	250708	SPACER	1
800	255691	GREASE	1
856	229733	BUSHING	1
856	825571	SPACER	1
856	889194	NUT	1
856	889195	BACKUP PAD	1