



<b>Ref #</b>	<b>Part #</b>	<b>Description</b>	<b>Context Note</b>	<b>Foot Note</b>
1	397662	Bearing Housing Assembly	Used Before Code Date 850725011	
1	399354	Housing Assembly-Bearing	Used After Code Date 850724011	
1	399578	Bearing Housing Assembly		
2	212888	Housing-Fan	Used Before Code Date 850725011	
2	213119	Housing-Fan	Used After Code Date 850724011	
2	394770	End Cap-Drive		
2	397666	End Cap-Drive		
3	395477	Ring Set-Retaining		
3	399809	Ring Set-Retaining		
4	395471	Screw/Washer Kit (Includes 2 Sets)		
5	394750	Housing-Motor (Includes Magnets)		
6	395468	Insulator-Housing (2 Pieces)		
7	396546	Armature Group		
7	397979	Armature Group		
7	398672	Armature & Fan Group		
7	399220	Armature & Fan Group		
7	399804	Armature Group		
8	280361	Box-Brush	Used Before Code Date 8512171	
8	280569	Box-Brush	Used After Code Date 8512161	
9	395467	Brush Set-Str (Includes Brush Holders)	Used Before Code Date 8512171	
9	398575	Brush Group (Includes Brush Holders And Retainers)	Used After Code Date 8512161	For Retainers Only Order Part No. 399187
10	395478	Lead Group		
11	394777	Rectifier		
12	394773	End Cap-Brush	Used Before Code Date 8512171	
12	398440	End Cap-Brush	Used After Code Date 8512161	
13	394769	Bearing-Needle		
14	399100	Cover-Motor		
15	231298	Nut-Hex.		
16	93852	Washer, Steel Zinc		
17	223461	Fan		

<b>Ref #</b>	<b>Part #</b>	<b>Description</b>	<b>Context Note</b>	<b>Foot Note</b>
17	491389	Fan		
20	92268	Washer-Lock (3/8 X 1/8 X 3/32")		
21	94052	Screw-Hex. Head	Used Before Code Date 850725011	
21	94151	Screw-Hex. Head	Used After Code Date 850724011	
22A	399569	Pump-Hydraulic		
23	94209	Screw-Hex. Head		
24	398135	Switch-Starter		
25	280594	Switch-Key		
26	280081	Socket-Regulator And Rectifier Lead Wire		
27	398270	Cord-Power Supply		
28	280556	Bushing-Cord		
29	223555	Bracket-Bushing		
31	399192	Motor Control (Four Conductor) (12 Amp)		
32	280593	Key Set (Includes 2 Keys)		
39	90366	Lockwasher, Zinc Pl	(Note: Used on all Type Nos. Except 0020,0112)	
39	90366	Lockwasher, Zinc Pl		