



Parts List for 78-431 Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|----------------------|--------------|
| 1 | 1350304S | SCREW | 1 |
| 2 | 1350276S | WASHER | 1 |
| 3 | 1350321S | ANTI-KICKBACK FINGER | 1 |
| 3 | 1350997S | WARNING LABEL | 1 |
| 4 | 1350320S | SPRING | 1 |
| 5 | 1352007S | SPLITTER ASSY | 1 |
| 5 | 1359124S | SPLITTER ASSY COMPLT | 1 |
| 6 | 1350321S | ANTI-KICKBACK FINGER | 1 |
| 7 | 1350276S | WASHER | 1 |
| 8 | 1350304S | SCREW | 1 |
| 9 | 1350277S | BOLT | 1 |
| 10 | 1351199S | FLAT WASHER | 1 |
| 12 | 1350305S | SCREW | 4 |
| 13 | 1352103S | COVER PLATE ASSY | 1 |
| 13 | 1350085S | KNOB | 1 |
| 13 | 1350084S | SPRING | 1 |
| 14 | 1352005S | SPLITTER MOUNT ASSY | 1 |
| 14 | 1352104S | RECEIVER ASSY | 1 |
| 15 | 1350308S | FLAT WASHER | 1 |
| 16 | 1350306S | WASHER | 1 |
| 17 | 1350307S | SCREW | 1 |
| 18 | 1350280S | LOCK NUT | 1 |