

Rotary tool - F 013 805 000 - 8050


www.powertools-aftersaleservice.com



BOSCH

Item	Part Number	Description	Illustration	Price	Quantity	Price Group
2	2 610 033 427	Motor	1	-,-	1	30
8	2 610 031 881	Label	1	-,-	1	13
23	2 610 031 874	Lens	1	-,-	1	11
24	1 619 X02 572	Screw	1	-,-	6	10
27	2 610 031 876	Push Button	1	-,-	1	10
28	2 610 031 877	Push Button	1	-,-	1	10
29	2 610 014 582	Nut	1	-,-	1	12
30	2 615 110 480	Collet 1/8"	1	-,-	1	15
33	2 610 033 160	Flange	1	-,-	1	11
34	2 910 648 880	Screw	1	-,-	2	10
651	2 610 930 692	Chuck Wrench	1	-,-	1	13
652	2 610 031 885	Charger	1	-,-	1	28
653	2 610 031 887	Charger	1	-,-	1	28
801	1 605 806 57S	Housing	1	-,-	1	29
804	1 600 A00 3M9	Electronic Module	1	-,-	1	42
822	1 600 A00 3M8	Locking Pin	1	-,-	1	14

Illustration - Type E



Information subject to change without further notice.