



# Air Compressor Diagram



# Compressor Pump Diagram



# Parts List

<b>KEY NO.</b>	<b>PART NUMBER</b>	<b>DESCRIPTION</b>
1	SSV-6	Globe Valve
2	CAC-4337	Check Valve
3	ABP-4900	Two-Stage Pump
4	BT-229	Belt
5	CAC-1357	Outside Belt Guard
6	CAC-1356	Inside Belt Guard
7	CAC-1004-1	Belt Guard Bracket
8	DAC-223	Outlet Tube
9	CAC-1367	Pressure Relief Tube
11	CAC-1355	Manifold
12	DAC-278-2	Pressure Switch Assembly
18	C-MO-3027	Motor for 919-177151
	MO-6437	Motor for 919-177252
19	SS-559	Set Screw
20	DAC-238 & 239	Split Pulley
21	SS-00403	Flywheel Direction Label
22	SS-2707	Drain Valve
24	SSF-3159	Pump Bolt
25	SSF-3140-ZN	Motor Bolt
26	SSF-8097	Speed Nut
27	SSF-8111-ZN	Lock Nut
28	SSF-953-ZN	Self Tapping Screw
29	SSF-989-ZN	Screw
31	SS-8553	Male Connector
33	TA-4267	Tank 80 gallon
36	TIA-4200	Safety Valve
37	SSP-7811	Nut Sleeve Assembly 1/4"
39	GA-360	Gauge
40	SSP-7812	Nut Sleeve Assembly 1/2"
41	DAC-225	Connector
	<b><u>NOT SHOWN</u></b>	
	KK-4315	Pressure Relief Valve Kit

# Parts List

<b>KEY NO.</b>	<b>PART NUMBER</b>	<b>DESCRIPTION</b>
1	KK-5039	Hardware Kit
2	ABP-4961400	Head
3	ABP-4950055	Gasket Kit
4	ABP-9053201	Oil Extension Tube
5	ABP-4000100	Flywheel
6	ABP-9022001	Sight Glass
7	ABP-4940050	Valve Plate Kit
8	ABP-9101164	Drain Plug Screw
9	ABP-9162030	Drain Plug Seal
10	ABP-9004008	Flywheel Washer
11	ABP-9110012	Flywheel Screw
12	ABP-9163010	Oil Seal
13	ABP-9013011	Shell Bearings (1 set)
* 14	ABP-8226504	HP Running Gear Kit
* 15	ABP-8226505	LP Running Gear Kit
16	ABP-4623050	HP Ring Kit
17	ABP-4924050	LP Ring Kit
18	ABP-4662000	Intercooler
19	ABP-4981000	Filter Replacement Kit (includes one #20)
20	ABP-4981100	Replacement Filter
21	ABP-9024014	Oil Fill Plug

\*Includes rings, piston pin, snap rings, oil dipper and split bearings.