



## Parts List for 9735 Type 1

Item Number	Part Number	Description	Qty Required
1	898877	ARMATURE	1
1	878904	FAN	1
2	898876	FIELD	1
3	874289	BRUSH & RETAINER ASY	2
3	865323	BRUSH HOLDER	2
3	865321	BRUSH INSULATOR	2
4	883498	SWITCH & TRIAC	1
5	A10193	CORDSET	1
11	855284	BEARING	3
11	883096	BEARING	3
15	883095	BEARING	3
31	879401	GEAR	1
40	N074353	RECIP-SHAFT KIT	1
52	912305	HOUSING	1
57	892792	HANDLE SET	1
81	897774	COLLAR	1
100	695077	MOUNTING BRKET TRIAC	1
101	690673	WIRE TIE	1
107	882703	SCREW	10
108	897576	INSULATOR BOOT	1
114	694432	BEARING MOUNT	1
121	882704	SCREW	10
125	879421	SCREW	10
130	879414	INTERMEDIATE PLATE	1
138	879458	PLATE	1
141	883097SV	DRIVE SHAFT	1
142	684931	WASHER	10

## Parts List for 9735 Type 1

Item Number	Part Number	Description	Qty Required
143	890819	WOBBLE PLATE	1
147	802302	RING	10
148	879429	SPACER	10
150	883213	CARRIER TUBE ASSY	1
153	882348	FELT SEAL	1
158	879423	FRONT HOUSING	1
159	879457	FELT SEAL	1
161	891672SV	SHOE & BRACKET ASSY.	1
163	849235	SCREW	10
165	879463	SCREW	10
181	900826	SCREW	10
187	892440	SET SCREW	10
188	880952	PLUG	1
190	853246	RING	10
196	882255	SCREW	10
197	648924-00	SPRING	10
198	884696	RETAINER KIT	1
199	648594-00	CLAMP PIN	10
203	902998	SEAL	1
206	846249	NUT	10
216	901266	STRAIN RELIEVER	1
217	802905	ALLEN WRENCH	1
218	842323	WRENCH HOLDER	1
219	879449	O RING	10
230	875914	TUBE GREASE	1
231	875667	LUBRICANT-4LBS	1
233	000000-00	No Longer Available	1

## Parts List for 9735 Type 1

Item Number	Part Number	Description	Qty Required
235	879447	PLUG	1
236	882187	SCREW	10
237	801852	SEAL	1