


PORTER-CABLE BATTERY HAMMER DRILLS

WARNING: Electrical repairs should only be attempted by trained repairmen. Contact the nearest Porter-Cable Service Center or other competent repair center.



**977
987**

Parts List for 977 Type 1

Item Number	Part Number	Description	Qty Required
1	905388	HANDLE SET	1
2	894098	SCREW	10
3	330075-91	KEYLESS CHUCK	1
4	905283	CLUTCH RING	1
5	905394	GEARBOX/CLUTCH	1
6	891238	PINION	1
7	889199	SCREW-CHEESE HD	10
8	000000-00	No Longer Available	1
9	907365	SCREW	10
10	895517	DRIVER BIT	1
11	000000-00	No Longer Available	1
12	893101	SWITCH	1
13	000000-00	No Longer Available	1
15	888993	SCREW	10
18	891352	RELEASE BUTTON	1
19	891353	SPRING	10
20	892955	CLIP	1
23	000000-00	No Longer Available	1
23	000000-00	No Longer Available	1
23	907471	MEDIUM GRIP	1
25	907442	PLASTIC RING	1
26	907440	BALL	1
27	907441	SPRING	10
28	907443	WASHER	10
29	000000-00	No Longer Available	10
30	000000-00	No Longer Available	10
32	905291	CARRYING CASE	1

Parts List for 977 Type 1

Item Number	Part Number	Description	Qty Required
35	000000-00	No Longer Available	1
36	901561	BATTERY TOP	1
41	8924	UNIVERSAL CHARGER	1
43	905271	SIDE HANDLE	1
50	000000-00	No Longer Available	1