



Parts List for AC7020 Type 1

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
2	168590-01	BRUSH ASSY	1
3	000000-00	No Longer Available	1
4	000000-00	No Longer Available	1
5	000000-00	No Longer Available	1
6	000000-00	No Longer Available	1
7	000000-00	No Longer Available	1
8	32114-06	CONNECTOR	1
9	000000-00	No Longer Available	1
10	000000-00	No Longer Available	1
11	000000-00	No Longer Available	1
12	283266-00	MOTOR ASSY	1
13	000000-00	No Longer Available	2
14	000000-00	No Longer Available	1
15	000000-00	No Longer Available	1
16	000000-00	No Longer Available	1
17	000000-00	No Longer Available	1
18	000000-00	No Longer Available	9
19	283271-00	SCREW, LONG	3
22	000000-00	No Longer Available	1
23	168588-00	ADAPTOR, HOSE	1
27	000000-00	No Longer Available	1