


RYOBI 4V BATTERY PACK – MODEL NO. AP4001 AND AP4003

The model number will be found on a label attached to the housing. Always mention the model number in all correspondence regarding your **BATTERY PACK** or when ordering replacement parts.



PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY.	KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	130166003	Battery Pack (AP4001)		NOT SHOWN: 988000312 Correlation Sheet 1 987000706 Operator's Manual 1 10-21-13 (REV:04)			
	130166021	Battery Pack (AP4001)					
	130166008	Battery Pack (AP4003)	1				
2	940976620	Data/Warning Label (AP4001)					
	940488211	Data/Warning Label (AP4001)					
	940032138	Data/Warning Label (AP4003) ...	1				