




# SPARE PARTS LIST

BATTERY PRODUCTS

B380X, B750X

**B380X, B750X  
PRODUCT COMPLETE**



PRODUCT COMPLETE

B380X, B750X

Ref	Part No	Description	Remark	QTY KIT	
1	970 49 41-01	BATTERY	B380X WITH BLUETOOTH - EU/AU/NZ/JP	1	
1	970 49 41-02	BATTERY	B380X WITH BLUETOOTH - US	1	
1	970 49 40-01	BATTERY	B380X WITHOUT BLUETOOTH - RoW	1	
1	970 49 42-01	BATTERY	B750X WITH BLUETOOTH - EU, AU, NZ, JP	1	
1	970 49 42-02	BATTERY	B750X WITH BLUETOOTH - US	1	
1	970 49 43-01	BATTERY	B750X WITHOUT BLUETOOTH - RoW	1	
2	596 33 10-01	COVER	B380X	1	1
2	596 33 12-01	COVER	B750X	1	1
3	531 04 88-01	HOUSING ASSY	B380X WITH BLUETOOTH - EU/AU/NZ/JP	1	1
3	531 04 88-02	HOUSING ASSY	B380X WITH BLUETOOTH - US	1	1
3	531 04 88-03	HOUSING ASSY	B380X WITHOUT BLUETOOTH - RoW	1	1
3	531 04 88-04	HOUSING ASSY	B750X WITH BLUETOOTH - EU, AU, NZ, JP	1	1
3	531 04 88-05	HOUSING ASSY	B750X WITH BLUETOOTH - US	1	1
3	531 04 88-06	HOUSING ASSY	B750X WITHOUT BLUETOOTH - RoW	1	1
4	599 49 49-01	CONTROL PANEL	WITH BLUETOOTH	1	1
4	599 31 41-01	CONTROL PANEL	WITHOUT BLUETOOTH	1	1
5	599 20 23-01	BRACKET		1	1
6	599 72 13-03	SCREW		4	1
7	529 96 50-01	DAMPER		8	1
8	597 41 03-01	COVER	B380X	1	1
8	597 41 02-01	COVER	B750X	1	1
9	599 72 13-02	SCREW	B380X	16	1
9	599 72 13-01	SCREW	B750X	16	1
10	599 71 35-01	LOGOTYPE	B380X	1	1
10	599 71 35-02	LOGOTYPE	B750X	1	1