



Parts List for BDCD12BC Type 1

Item Number	Part Number	Description	Qty Required
4	90618579	KEYLESS CHUCK	1
5	N569223	ACTUATOR FWR/REV	1
7	149518-01	SCREW	1
8	5101046-00	SCREW	8
9	5100035-03	SPRING	2
856	90541186	BIT	1
866	90618230	BATTERY PACK	1
871	LCS1620	CHARGER	1