



Parts List for BDCDD120C Type 1

Item Number	Part Number	Description	Qty Required
1	90623140	HOUSING ASSEMBLY	1
2	90626851	MOTOR & GEARBOX	1
3	90621521	SWITCH ASSEMBLY	1
4	90554689	ACTUATOR	1
5	5100035-03	SPRING	2
6	90618579-01	KEYLESS CHUCK	1
7	5101046-00	SCREW	7
8	5101046-01	SCREW	2
10	148354-03	BIT CLIP	1
11	149518-01	SCREW	1
12	90625041	RATING LABEL	1
866	LBXR20	BATTERY	1
871	90590282-02	CHARGER	1