




# SPARE PARTS LIST


SURFACE PREPARATION EQUIPMENT

BG 300, 2022-04



| Ref | Part No      | Description        | Remark             | QTY KIT |
|-----|--------------|--------------------|--------------------|---------|
| 1   | 533 15 67-01 | HANDLE             | HANDLE             | 1       |
| 2   | 533 25 89-01 | CONTROL PLATE      | CONTROL PLATE      | 1       |
| 3   | 535 95 58-01 | SWITCH             | SWITCH             | 1       |
| 4   | 535 95 59-01 | SWITCH             | SWITCH             | 1       |
| 5   | 533 77 27-01 | FREQUENCY INVERTER | FREQUENCY INVERTER | 1       |
| 5   | 533 93 63-01 | FREQUENCY INVERTER | FREQUENCY INVERTER | 1       |
| 5   | 534 07 09-01 | FREQUENCY INVERTER | FREQUENCY INVERTER | 1       |
| 6   | 533 10 97-01 | CLAMP              | CLAMP              | 2       |
| 7   | 535 30 85-01 | HANDLE             | HANDLE             | 1       |
| 8   | 900 00 00-02 | DUMMY PART         | DUMMY PART         | 1       |
| 8   | 535 92 48-01 | UNIT               | UNIT               | 2       |
| 9   | 533 19 73-01 | CONTROL            | CONTROL            | 1       |
| 10  | 535 92 58-01 | ARM                | ARM                | 1       |
| 11  | 534 07 09-01 | FREQUENCY INVERTER | FREQUENCY INVERTER | 2       |
| 11  | 535 92 25-01 | DECAL              | DECAL              | 2       |
| 12  | 900 00 00-02 | DUMMY PART         | DUMMY PART         | 1       |
| 13  | 900 00 00-02 | DUMMY PART         | DUMMY PART         | 1       |
| 14  | 535 92 70-01 | TOOL               | TOOL               | 1       |
| 15  | 900 00 00-02 | DUMMY PART         | DUMMY PART         | 1       |
| 16  | 535 92 42-01 | PLATE              | PLATE              | 1       |
| 17  | 535 92 52-01 | UNIT               | UNIT               | 1       |
| 17  | 535 92 53-01 | UNIT               | UNIT               | 1       |

BG 300E  
WHEEL RACK UNIT




## WHEEL ASSY

BG 300, 2022-04

| Ref | Part No      | Description | Remark     | QTY KIT |
|-----|--------------|-------------|------------|---------|
| 1   | 535 91 55-01 | FRAME       | FRAME      | 1       |
| 2   | 535 91 62-01 | FRAME       | FRAME      | 1       |
| 3   | 535 92 29-01 | AXLE        | AXLE       | 1       |
| 4   | 535 92 27-01 | AXLE        | AXLE       | 4       |
| 5   | 535 92 40-01 | PLATE       | PLATE      | 2       |
| 6   | 533 48 17-01 | BOLT        | BOLT       | 4       |
| 7   | 533 08 71-01 | WHEEL       | WHEEL      | 2       |
| 8   | 900 00 00-02 | DUMMY PART  | DUMMY PART | 2       |
| 9   | 533 62 65-01 | WHEEL       | WHEEL      | 2       |
| 10  | 533 27 83-01 | BOLT        | BOLT       | 2       |
| 11  | 535 92 20-01 | PIPE        | PIPE       | 1       |
| 12  | 533 53 83-01 | PIN         | PIN        | 2       |
| 13  | 900 00 00-02 | DUMMY PART  | DUMMY PART | 1       |

BG 300E  
GRINDING HEAD UNIT




## GRINDING HEAD

BG 300, 2022-04

| Ref | Part No      | Description    | Remark         | QTY KIT |
|-----|--------------|----------------|----------------|---------|
| 1   | 533 36 96-01 | UNIT           | UNIT           | 1       |
| 2   | 533 26 31-01 | BRUSH          | BRUSH          | 2       |
| 3   | 533 26 32-01 | BRUSH          | BRUSH          | 1       |
| 4   | 533 10 98-01 | COVER          | COVER          | 2       |
| 5   | 533 26 33-01 | BRUSH          | BRUSH          | 1       |
| 6   | 900 00 00-02 | DUMMY PART     | DUMMY PART     | 4       |
| 7   | 535 92 37-01 | PLATE          | PLATE          | 2       |
| 8   | 533 28 60-01 | WHEEL          | WHEEL          | 4       |
| 9   | 533 24 17-01 | BEARING SLEEVE | BEARING SLEEVE | 4       |
| 10  | 533 50 46-01 | NUT            | NUT            | 4       |
| 11  | 533 21 53-01 | MOTOR          | MOTOR          | 1       |
| 11  | 535 67 89-01 | MOTOR          | MOTOR          | 1       |
| 11  | 535 92 77-01 | MOTOR          | MOTOR          | 1       |
| 12  | 900 00 00-02 | DUMMY PART     | DUMMY PART     | 2       |
| 13  | 900 00 00-02 | DUMMY PART     | DUMMY PART     | 2       |
| 14  | 535 91 72-01 | COUPLING       | COUPLING       | 1       |
| 15  | 535 92 41-01 | KNOB           | KNOB           | 2       |
| 16  | 900 00 00-02 | DUMMY PART     | DUMMY PART     | 4       |
| 17  | 900 00 00-02 | DUMMY PART     | DUMMY PART     | 1       |
| 18  | 533 05 10-01 | HOUSING        | HOUSING        | 1       |

BG 300E  
GRINDER DISC UNIT





GRINDING HEAD

BG 300, 2022-04

| Ref | Part No      | Description     | Remark          | QTY KIT |
|-----|--------------|-----------------|-----------------|---------|
| 1   | 533 52 35-01 | ADAPTER         | ADAPTER         | 1       |
| 2   | 533 62 52-01 | ADAPTER         | ADAPTER         | 1       |
| 3   | 533 34 91-01 | SPACER RING     | SPACER RING     | 3       |
| 4   | 533 35 53-01 | COUPLING        | COUPLING        | 1       |
| 5   | 533 21 52-01 | PLATE           | PLATE           | 1       |
| 6   | 535 91 85-01 | SHAFT           | SHAFT           | 1       |
| 7   | 535 92 45-01 | UNIT            | UNIT            | 1       |
| 8   | 535 91 88-01 | BEARING HOUSING | BEARING HOUSING | 1       |
| 9   | 535 92 43-01 | UNIT            | UNIT            | 1       |
| 10  | 900 00 00-02 | DUMMY PART      | DUMMY PART      | 1       |
| 11  | 900 00 00-02 | DUMMY PART      | DUMMY PART      | 1       |