



BRN175

15° COIL ROOFING NAILER
 15° BOBINA CLAVADORA PARA TECHADO
 15° CLOUEUSE POUR TOITURE


24-26 IN-LBS
 OF TORQUE
 (28-31 KG-CM)



79-89 IN-LBS
 OF TORQUE
 (92-103 KG-CM)
 4 PLACES APPLY
 MEDIUM
 STRENGTH
 THREAD LOCK



145-155 IN-LBS
 OF TORQUE
 (167-178 KG-CM)
 4 PLACES



18-25 IN-LBS
 OF TORQUE
 (21-29 KG-CM)

18-25 IN-LBS
 OF TORQUE
 (21-29 KG-CM)

IP1437-1RA 01/15
 TO BE USED WITH PARTS LIST IP1437-2 AND OPERATION AND MAINTENANCE MANUAL 9R209323.

Parts List for BRN175 Type 0

Item Number	Part Number	Description	Qty Required
1	174041	SCREW-SFHCS-M4X0.7X1	1
2	174042	SPACER-EXHAUST COVER	1
3	9R195034	EXHAUST COVER	1
4	850242	O-RING-1.799X.103	2
5	MSC5080-22	SCREW-SHCS-M5X0.8X22	5
6	9R209521	FRAME CAP	1
7	9R195064	GASKET	1
8	9R195037	HEAD VALVE SEAL	1
9	180532	SPRING-HEAD VALVE	1
10	9R184442	O-RING	1
11	850605	O-RING-1.925X.103-NB	1
12	9R217638	HEAD VALVE ASSEM	1
13	9R184444	O-RING	1
14	184443	O-RING	1
15	9R195039	O-RING	1
16	9R217631	DRIVER/PISTON ASSY	1
17	9R195044	COLLAR	1
18	9R184446	O-RING	1
19	9R184448	O-RING	1
20	9R215134	CYLINDER SLEEVE	1
21	105816	O-RING-1.674X.103	1
22	9R184456	FLAT WASHER	1
23	9R209523	FRAME	1
24	9R209524	END CAP	1
25	184519	PIN-TRIGGER LOCK	1
26	9R195625	O-RING	2
27	174345	PIN SPRING	3

Parts List for BRN175 Type 0

Item Number	Part Number	Description	Qty Required
28	180475	PIN-SPRING-M3X20MM	2
29	184507	PIN-MODE SWITCH	1
30	9R188850	MODE SPRING	1
31	9R195051	CONTACT ARM SPRING	1
32	9R195007	CONTACT ARM ASSY.	1
33	9R195027	ADJUSTING SCREW	1
34	9R184457	E-RING	1
35	9R195528	BUMPER	1
36	9R195050	GASKET	1
37	9R195026	BUSHING	1
38	MHE5080-100	NUT-NYLON M5X.80	2
39	9R195005	FEED PAWL	1
40	9R195052	SPRING GUARD	1
41	9R195545	SOCKET HEAD CAP SCRE	4
42	9R195010	NOSE-MACHINING	1
43	N12112	HINGE PIN RETAINER	4
44	9R195053	DOOR PIVOT PIN	1
45	9R195059	DOOR ASSEMBLY	1
46	N494651	SOC HD CAP M5 X20	1
47	9R184447	O-RING	1
48	149882	PIN-CHECK PAWL	1
49	149859	SPRING-FEED PAWL	1
50	9R195011	FEED PISTON	1
51	88998	O-RING	1
52	149887	SPRING-FEED PISTON	1
53	9R195004	FEED PISTON STOP	1
54	9R195008	SPRING COLLAR	1

Parts List for BRN175 Type 0

Item Number	Part Number	Description	Qty Required
55	9R184453	C-RING	1
56	9R195049	CONTACT ARM GUIDE	1
57	180509	ADJUSTING KNOB	1
58	180510	ASSEMBLY-UPPER CONTA	1
59	180513	SPRING	1
60	180514	GUIDE-UPPER TRIP	1
61	9R195699	TRIGGER LOCK BUTTON	1
62	TVA22	TRIGGER VALVE	1
63	180476	SPRING-TRIGGER	1
64	9R202299	TRIGGER	1
65	184508	BUSHING	1
66	9R195079	BUTTON-MODE SWITCH	1
67	180484	SCREW-SET-M3X8MM	1
68	9R209520	MAGAZINE ASSEMBLY	1
69	184432	COVER	1
70	9R195624	QUICK CONNECT	1
71	9R210033	BOSTITCH LOGO LABEL	2
72	9R210051	WARNING LABEL BRN175	1
73	9R210052	WARNING LABEL	1
74	9R210055	MODEL LABEL BRN175	1
75	9R188713	SPRING	3
76	9R191796	DOOR SPRING	1
77	9R195033	CHECK PAWL PIN	1
78	9R195055	DOOR-MACHINING	1
79	9R195056	CHECK PAWL	3
80	9R195057	DOOR LATCH	1
81	MPG030010	PIN-ROLL-3MM X 10MM	1